

SMICE-PS COMMANDS REFERENCE



DOCUMENT RELEASED BY:

CUSTOM ENGINEERING S.p.A.

Via Berettine 2 – 43010 Fontevivo (Parma) - Italy

All rights reserved

Cod. DOMC-SMICE-PS-E

Rev. 1.20

COMMAND DESCRIPTION

1.1 COMMAND DESCRIPTIONS

1.1.1 ESC/POS Emulation

The following table lists all the commands for function management in ESC/POS™ Emulation of the printer. The commands can be transmitted to the printer at any moment, but they will only be carried out when the commands ahead of them have been executed. The commands are carried out when the circular buffer is free to do so. The table 1.1 shows the commands list, ordered by their hexadecimal value.

LEGEND :

Symbol	Function
\$	indicates the representation of the command hexadecimal value (for example \$40 means HEX 40).
{ }	indicates an ASCII character not performable.
n, m, t, x, y	are optional parameters that can have different values.

COMMAND DESCRIPTION TABLE

(Tab.1.1)

ASCII	HEX	Description
BS	\$08	Back space
HT	\$09	Horizontal tab
LF	\$0A	Print and line feed
FF	\$0C	Print and return to standard mode in page mode
CR	\$0D	Print and carriage return
DLE EOT n	\$10 \$04 (n)	Real-time status transmission
DLE ENQ n	\$10 \$05 n	Real-time request to printer
DLE DC4 n m t	\$10 \$14 n m t	Generate pulse at real-time
CAN	\$18	Cancel print data in page mode
ESC SP n	\$1B \$20 (n)	Set character right-side spacing
ESC ! n	\$1B \$21 (n)	Set print mode
ESC \$ nL nH	\$1B \$24 nL nH	Set absolute position
ESC % n	\$1B \$25 (n)	Select/cancel user-defined character set
ESC & y c1 c2	\$1B \$26 y c1 c2	Define user-defined characters
ESC (v nL nH	\$1B \$28 \$76 nL nH	Set relative vertical print position
ESC * m nL nH d1...dk	\$1B \$2A m nL nH d1...dk	Select image print mode
ESC - n	\$1B \$2D (n)	Turn underline mode on/off
ESC 0	\$1B \$30	Select 1/8-inch line spacing
ESC 2	\$1B \$32	Select 1/6-inch line spacing
ESC 3 n	\$1B \$33 (n)	Set line spacing using minimum units
ESC 4 n	\$1B \$34 (n)	Set/reset script mode
ESC = n	\$1B \$3D (n)	Select device
ESC ? n	\$1B \$3F (n)	Cancel user-defined characters
ESC @	\$1B \$40	Initialize printer
ESC D n1...nk NUL	\$1B \$44 n1...nk 00	Set horizontal tab positions
ESC E n	\$1B \$45 (n)	Select emphasized mode
ESC G n	\$1B \$47 (n)	Select double-strike mode
ESC J n	\$1B \$4A (n)	Print and feed paper
ESC L	\$1B \$4C	Select page mode
ESC M n	\$1B \$4D n	Select character font
ESC R n	\$1B \$52 (n)	Select international character set
ESC S	\$1B \$53	Select standard mode
ESC T n	\$1B \$54 (n)	Select print direction in page mode

COMMAND DESCRIPTION

ASCII	HEX	Description
ESC V n	\$1B \$56 (n)	Select print mode 90° turned
ESC W xL xH yL yH dxL dxH dyL dyH	\$1B \$57 xL xH yL yH dxL dxH dyL dyH	Set printing area in page mode
ESC \ nL nH	\$1B \$5C nL nH	Set relative print position
ESC a n	\$1B \$61 (n)	Select justification
ESC c 3 n	\$1B \$63 \$33 (n)	Select paper sensor(s) to output paper end signals
(s)ESC d n	\$1B \$64 (n)	Print and feed paper n lines
ESC i	\$1B \$69	Total cut
ESC m	\$1B \$6D	Partial cut
ESC p m t1 t2	\$1B \$70 m t1 t2	Generate pulse
ESC r n	\$1B \$72 (n)	Set / reset red printing mode
ESC t n	\$1B \$74 (n)	Select character code table
ESC u n	\$1B \$75 (n)	Transmit peripheral device status
ESC v	\$1B \$76	Transmit printer status
ESC { n	\$1B \$7B (n)	Set/cancel upside-down character printing
ESC {} n	\$1B \$C1 n	Set/cancel cpi mode
ESC {} n xL xH yH yL	\$1B \$FA n xL xH yH yL	Print graphic
ESC {} nL nH	\$1B \$FB nL nH	Transmit graphic page to communication port
ESC {} \$FB nL nH	\$1B \$FC n	Transfer flash bank into graphic page
ESC {} nL nH	\$1B \$FD nL nH	Receive graphic page from communication port
ESC n	\$1B \$FE (n)	Transfer graphic page into flash bank
ESC }	\$1B \$FF	Print data in page mode
FS p n m	\$1C \$70 n m	Print NV bit image
FS q n [xL xH yL yH d1...dk]1...[xL xH yL yH yH d1...dk]n	\$1C \$71 n [xL xH yL yH d1...dk]1...[xL xH yL yH d1...dk]n	Define NV bit image
GS ! n	\$1D \$21 (n)	Select character size
GS \$ nL nH	\$1D \$24 nL nH	Set absolute vertical print position in page mode
GS * x y d1..d(x x y x 8)	\$1D \$2A x y d1..d(x x y x 8)	Define downloaded bit image
GS / m	\$1D \$2F m	Print downloaded bit image
GS :	\$1D \$3A	Set start/end of macro definition
GS B n	\$1D \$42 (n)	Turn white/black reverse printing mode on/off
GS C 0 n m	\$1D \$43 \$30 n m	Select counter print mode
GS C 1 aL aH bL bH n r	\$1D \$43 \$31 aL aH bL bH n r	Select count mode (A)
GS C 2 nL nH	\$1D \$43 \$32 nL nH	Select counter
GS C ; sa ; sb ; sn ; sr ; sc ;	\$1D \$43 \$3B sa \$3B sb \$3B sn \$3B sr \$3B sc \$3B	Select count mode (B)
GS H n	\$1D \$48 (n)	Select printing position of HRI characters
GS I n	\$1D \$49 (n)	Transmit printer ID
GS L nL nH	\$1D \$4C nL nH	Set left margin
GS P x y	\$1D \$50 x y	Set horizontal and vertical motion units
GS W nL nH	\$1D \$57 nL nH	Set printing area width
GS \ nL nH	\$1D \$5C nL nH	Set relative vertical print position in page mode
GS ^ r t m	\$1D \$5E r t m	Execute macro
GS c	\$1D \$63	Print counter
GS f n	\$1D \$66 n	Select font for HRI characters
GS h n	\$1D \$68 n	Select height of bar code
GS k m NUL	\$1D \$6B m \$00	Print bar code

COMMAND DESCRIPTION

ASCII	HEX	Description
GS r n	\$1D \$72 n	Transmit status
GS w n	\$1D \$77 n	Select horizontal side (enlargement) of bar code
GS { } n	\$1D \$7C n	Set printing density
GS { } n	\$1D \$7E n	Set superscript/subscript
GS { } n	\$1D \$F0 n	Set printing speed
GS { } n	\$1D \$F1 n	Set current print consumption
GS { }	\$1D \$F6	Ticket align at first line
GS { }	\$1D \$F8	Ticket align at cut

Given below are more detailed descriptions of each command.

BS

[Name]	Back space	
[Format]	ASCII	BS
	Hex	08
	Decimal	8
[Description]	Moves print position to previous character.	
[Notes]	Can be used to put two characters at the same position.	
[Default]		
[Reference]		
[Example]		

HT

[Name]	Horizontal tab	
[Format]	ASCII	HT
	Hex	09
	Decimal	9
[Description]	Moves the print position to the next horizontal tab position.	
[Notes]	<ul style="list-style-type: none"> • Ignored unless the next horizontal tab position has been set. • If the command is received when the printing position is at the right margin, the printer executes print buffer full printing and horizontal tab processing from the beginning of the next line. • Horizontal tab positions are set using ESC D. 	
[Default]		
[Reference]	ESC D	
[Example]		

LF

[Name]	Print and line feed	
[Format]	ASCII	LF
	Hex	0A
	Decimal	10
[Description]	Prints the data in the buffer and feeds one line based on the current line spacing.	
[Notes]	• Sets the print position to the beginning of the line.	
[Default]		
[Reference]	ESC 2, ESC 3	
[Example]		

FF

[Name]	Print and return to standard mode in page mode						
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>FF</td> </tr> <tr> <td>Hex</td> <td>0C</td> </tr> <tr> <td>Decimal</td> <td>12</td> </tr> </table>	ASCII	FF	Hex	0C	Decimal	12
ASCII	FF						
Hex	0C						
Decimal	12						
[Description]	Prints the data in the buffer collectively and returns to standard mode.						
[Notes]	<ul style="list-style-type: none"> • The buffer data is deleted after being printed. • The printing area set by ESC W is reset to the default setting. • The printer does not execute paper cutting. • This command sets the print position to the beginning of the line. • This command is enabled only in page mode. 						
[Default]							
[Reference]	ESC FF, ESC L, ESC S						
[Example]							

CR

[Name]	Print and carriage return						
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>CR</td> </tr> <tr> <td>Hex</td> <td>0D</td> </tr> <tr> <td>Decimal</td> <td>13</td> </tr> </table>	ASCII	CR	Hex	0D	Decimal	13
ASCII	CR						
Hex	0D						
Decimal	13						
[Description]	When autofeed is “CR enabled”, this command functions in the same way as LF , otherwise it is disregarded.						
[Notes]	<ul style="list-style-type: none"> • Sets the print position to the beginning of the line. 						
[Default]	See “Autofeed in setup” parameter.						
[Reference]	LF						
[Example]							

DLE EOT n

[Name]	Real-time status transmission												
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>DLE</td> <td>EOT</td> <td>n</td> </tr> <tr> <td>Hex</td> <td>10</td> <td>04</td> <td>n</td> </tr> <tr> <td>Decimal</td> <td>16</td> <td>4</td> <td>n</td> </tr> </table>	ASCII	DLE	EOT	n	Hex	10	04	n	Decimal	16	4	n
ASCII	DLE	EOT	n										
Hex	10	04	n										
Decimal	16	4	n										
[Range]	$1 \leq n \leq 17$												
[Description]	<p>Transmits the selected printer status specified by <i>n</i> in real time according to the following parameters:</p> <ul style="list-style-type: none"> n = 1 transmit printer status n = 2 transmit off-line status n = 3 transmit error status n = 4 transmit paper roll sensor status n = 17 transmit print status 												
[Notes]	<ul style="list-style-type: none"> • Immediately executed even when the data buffer is full. <p>This status is transmitted whenever data sequence 10H 04H n ($1 \leq n \leq 17$) is received.</p>												
[Default]													
[Reference]	See tables below.												
[Example]													

COMMAND DESCRIPTION

n=1: Printer status

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Not used. Fixed to Off.
1	On	02	2	Not used. Fixed to On.
2	Off	00	0	Drawer kick-out signal Low (pin 3).
	On	04	4	Drawer kick-out signal High (pin 3).
3	Off	00	0	On-line.
	On	08	8	Off-line.
4	On	10	16	Not used. Fixed to On.
5	-	-	-	Undefined.
6	-	-	-	Undefined.
7	Off	00	0	Not used. Fixed to Off.

n=2: Off-line status

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Not used. Fixed to Off.
1	On	02	2	Not used. Fixed to On.
2	Off	00	0	Cover open.
	On	04	4	Cover close.
3	Off	00	0	Paper is not being fed by FEED button.
	On	08	8	Paper is being fed by FEED button.
4	On	10	16	Not used. Fixed to On.
5	Off	00	0	No paper end stop.
	On	20	32	Printing stops due to paper end.
6	Off	00	0	No error.
	On	40	64	Error.
7	Off	00	0	Not used. Fixed to Off.

n=3: Error status

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Not used. Fixed to Off.
1	On	02	2	Not used. Fixed to On.
2	Off	00	0	Not used. Fixed to Off.
3	Off	00	0	Cutter OK.
	On	08	8	Cutter error.
4	On	10	16	Not used. Fixed to On
5	Off	00	0	No unrecoverable error.
	On	20	32	Unrecoverable error occurs (cutter, memory, RTCK,FPGA).
6	Off	00	0	No auto-recoverable error.
	On	40	64	Auto-recoverable error (overtemperature, parity, wrong command).
7	Off	00	0	Not used. Fixed to Off

n=4: Paper roll sensor status

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Not used. Fixed to Off.
1	On	02	2	Not used. Fixed to On.
2	Off	00	0	Not used. Fixed to Off.
3	Off	00	0	Not used. Fixed to Off.
4	On	10	16	Not used. Fixed to On
5, 6	On	60	96	Fixed to On. Paper end detected by paper end sensor.
7	Off	00	0	Not used. Fixed to Off

n=17: Print status

COMMAND DESCRIPTION

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Not used. Fixed to Off.
1	On	02	2	Not used. Fixed to On.
2	Off	00	0	Paper drag motor off.
	On	04	4	Paper drag motor on
3	Off	00	0	Not used. Fixed to Off.
4	On	10	16	Not used. Fixed to On
5	Off	00	0	Paper adequate
	On	20	32	The print is stopped; paper out error occurs.
6	Off	00	0	Motor temperature OK
	On	40	64	Overtemperature motor error occurs
7	Off	00	0	Not used. Fixed to Off

DLE ENQ n

[Name] **Real-time request to printer**

[Format] ASCII DLE ENQ n
Hex 10 05 n
Decimal 16 5 n

[Range] $1 \leq n \leq 2$

[Description] Responds to a request from the host computer, *n* specifies the request as follows:

n	Request
1	Recover from an error and restart printing from the line where the error occurred
2	Recover from an error after clearing the receive and print buffers

- [Notes]
- This command is effective only when an auto-cutter error occurs.
 - The printer starts processing data upon receiving this command.
 - This command is executed even when the printer is off-line, the receive buffer is full, or there is an error status.
 - This command can not be executed when the printer is busy.
 - The status is also transmitted whenever the data sequence of <10>H<05>H<n> ($1 \leq n \leq 2$) is received.

Example:

In **ESC * m nL nH dk**, d1 = <10>H, d2 = <05>H, d3 = <01>H

- This command should not be contained within another command that consists of two or more bytes.

Example:

If you attempt to transmit **ESC 3 n** to the printer, but DTR (DSR for the host computer) goes to MARK before *n* is transmitted, and **DLE ENQ 2** interrupts before *n* is received, the code <10>H for **DLE ENQ 2** is processed as the code for **ESC 3 <10>H**.

- **DLE ENQ 2** enables the printer to recover from an error after clearing the data in the receive buffer and the print buffer. The printer retains the settings (by **ESC !**, **ESC 3**, etc.) that were in effect when the error occurred. The printer can be initialized completely by using this command and **ESC @**. This command is enabled only for errors that have the possibility of recovery, except for print head temperature error.

- When the printer is disabled with **ESC =** (Select peripheral device), the error recovery functions (**DLE ENQ 1** and **DLE ENQ 2**) are enabled, and the other functions are disabled.

[Default]

[Reference] **DLE EOT**

[Example]

COMMAND DESCRIPTION

DLE DC4 n m t

[Name]	Generate pulse at real-time					
[Format]	ASCII	DLE	DC4	n	m	t
	Hex	10	14	n	m	t
	Decimal	16	20	n	m	t
[Range]	n = 1 m = 0,1 1 ≤ t ≤ 8					
[Description]	Outputs the pulse specified by the connector pin <i>m</i> as follows:					

m	Connector pin
1	Drawer kick-out connector pin 2.
2	Drawer kick-out connector pin 5.

[Notes]	<p>The pulse ON time is [t x 100 ms] and the OFF time is [t x 100 ms].</p> <ul style="list-style-type: none">• When the printer is in an error status when this command is processed, this command is ignored.• When the pulse is output to the connector pin specified while ESC p or DLE DC4 is executed while this command is processed, this command is ignored.• The printer executes this command upon receiving it.• This command is executed even when the printer is off-line, the receive buffer is full, or there is an error status.• This command cannot be executed when the printer is busy.• If print data includes the same character strings as this command, the printer performs the same operation specified by this command. The user must consider this.• This command should not be used within the data sequence of another command that consists of 2 or more bytes.• This command is effective even when the printer is disabled with ESC = (Select peripheral device).
[Default]	
[Reference]	ESC p
[Example]	

CAN

[Name]	Cancel print data in page mode
[Format]	ASCII CAN Hex 18 Decimal 24
[Description]	In page mode, deletes all the print data in the current printable area.
[Notes]	<ul style="list-style-type: none">• This command is enabled only in page mode.• If data that existed in the previously specified printing area also exists in the currently specified printing area, it is deleted.
[Default]	
[Reference]	ESC L, ESC W
[Example]	

ESC SP n

[Name]	Set right-side character spacing												
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>ESC</td> <td>SP</td> <td>n</td> </tr> <tr> <td>Hex</td> <td>1B</td> <td>20</td> <td>n</td> </tr> <tr> <td>Decimal</td> <td>27</td> <td>32</td> <td>n</td> </tr> </table>	ASCII	ESC	SP	n	Hex	1B	20	n	Decimal	27	32	n
ASCII	ESC	SP	n										
Hex	1B	20	n										
Decimal	27	32	n										
[Range]	$0 \leq n \leq 255$												
[Description]	Sets the character spacing for the right side of the character to [n x horizontal or vertical motion units].												
[Notes]	<ul style="list-style-type: none"> • The right character spacing for double-width mode is twice the normal value. When the characters are enlarged, the right side character spacing is m (2 or 4) times the normal value. • The horizontal and vertical motion units are specified by GS P. Changing the horizontal or vertical motion units does not affect the current right side spacing. • The GS P command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount. • In standard mode, the horizontal motion unit is used. • The maximum right side spacing is 255/200 inches. 												
[Default]	n = 0												
[Reference]	GS P												
[Example]													

ESC ! n

[Name]	Select print modes												
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>ESC</td> <td>!</td> <td>n</td> </tr> <tr> <td>Hex</td> <td>1B</td> <td>21</td> <td>n</td> </tr> <tr> <td>Decimal</td> <td>27</td> <td>33</td> <td>n</td> </tr> </table>	ASCII	ESC	!	n	Hex	1B	21	n	Decimal	27	33	n
ASCII	ESC	!	n										
Hex	1B	21	n										
Decimal	27	33	n										
[Range]	$0 \leq n \leq 255$												
[Description]	Selects print modes using <i>n</i> (see table below):												

Bit	Off/On	Hex	Decimal	Function	11/15 cpi	15/20 cpi
0	Off	00	0	Character font A selected.	18 x 24	13 x 24
	On	01	1	Character font B selected.	13 x 24	10 x 24
1	-	-	-	Undefined.		
2	-	-	-	Undefined.		
3	Off	00	0	Expanded mode not selected.		
	On	08	8	Expanded mode selected.		
4	Off	00	0	Double-height mode not selected.		
	On	10	16	Double-height mode selected.		
5	Off	00	0	Double-width mode not selected.		
	On	20	32	Double-width mode selected.		
6	Off	00	0	Italic mode not selected.		
	On	40	64	Italic mode selected.		
7	Off	00	0	Underline mode not selected.		
	On	80	128	Underline mode selected.		

[Notes]	<ul style="list-style-type: none"> • The printer can underline all characters, but cannot underline the spaces set by HT, ESC \$, ESC \ and 90°/270° rotated characters. • When characters are enlarged to different heights on one line, the characters are aligned at the baseline or topline (see GS ~). • This command resets the left and right margin at default value (see GS L, GS W). • ESC E can also be used to turn the emphasized mode on/off. However, the last-received setting command is the effective one. • ESC - can also be used to turn the underlining mode on/off. However, the last-received
---------	--

COMMAND DESCRIPTION

setting command is the effective one.

- **ESC 4** can also be used to turn the italic mode on/off. However, the last-received setting command is the effective one.

- **GS !** can also be used to select character height/width. However, the last-received setting command is the effective one.

[Default]

n = 0

[Reference]

ESC -, ESC E, ESC 4, GS !

[Example]

ESC \$ nL nH

[Name]

Set absolute print position

[Format]

ASCII	ESC	\$	nL	nH
Hex	1B	24	nL	nH
Decimal	27	36	nL	nH

[Range]

$0 \leq nL \leq 255$
 $0 \leq nH \leq 255$

[Description]

Sets the distance from the beginning of the line to the position at which subsequent characters are to be printed.

The distance from the beginning of the line to the print position is $[(nL + nH \times 256) \times (\text{vertical or horizontal motion unit})]$ inches.

[Notes]

- Settings outside the specified printable area are ignored.
- The horizontal and vertical motion unit are specified by **GS P**.
- **GS P** can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount.
- In standard mode, the horizontal motion unit (x) is used.
- If the setting is outside the printing area width, it sets the absolute print position, but the left or right margin is set at default value.

[Default]

[Reference]

ESC \, GS P

[Example]

ESC % n

[Name]

Select/cancel user-defined characters

[Format]

ASCII	ESC	%	n
Hex	1B	25	n
Decimal	27	37	n

[Range]

$0 \leq n \leq 255$

[Description]

Selects or cancels the user-defined character set.

When the Least Significant Bit (LSB) of n is 0, the user-defined character set is canceled.

When the LSB of n is 1, the user-defined character set is selected.

[Notes]

- Only the LSB of n is applicable.
- When the user-defined character set is canceled, the internal character set is automatically selected.

[Default]

n=0

[Reference]

ESC &, ESC ?

[Example]

ESC & y c1 c2 [x1 d1...d(y x x1)]...[xkd1...d(y x xk)]

[Name]	Defines user-defined characters																		
[Format]	<table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">ASCII</td> <td style="width: 10%;">ESC</td> <td style="width: 10%;">&</td> <td style="width: 10%;">y</td> <td style="width: 10%;">c1</td> <td style="width: 10%;">c2</td> </tr> <tr> <td>Hex</td> <td>1B</td> <td>26</td> <td>y</td> <td>c1</td> <td>c2</td> </tr> <tr> <td>Decimal</td> <td>27</td> <td>37</td> <td>y</td> <td>c1</td> <td>c2</td> </tr> </table>	ASCII	ESC	&	y	c1	c2	Hex	1B	26	y	c1	c2	Decimal	27	37	y	c1	c2
ASCII	ESC	&	y	c1	c2														
Hex	1B	26	y	c1	c2														
Decimal	27	37	y	c1	c2														
[Range]	<p>y = 3 $32 \leq c1 \leq c2 \leq 126$ $0 \leq x \leq 16$ (Font (18 × 24)) $0 \leq x \leq 10$ (Font (10 × 24)) $0 \leq x \leq 8$ (Font 8 × 24) $0 \leq d1 \dots d (y \times xk) \leq 255$ $k = c2 - c1 + 1$</p>																		
[Description]	<p>Defines user-defined characters. Y specifies the number of bytes in the vertical direction. C1 specifies the beginning character code for the definition, and C2 specifies the final code. X specifies the number of dots in the horizontal direction.</p>																		
[Notes]	<ul style="list-style-type: none"> • The allowable character code range is from ASCII 20H (32) to 7EH (126) (95 characters). • It is possible to define multiple characters for consecutive character codes. If only one character is desired, use $c1 = c2$. • If $c2 < c1$, the command is not executed. • d is the dot data for the characters. The dot pattern is in the horizontal direction starting from the left. Any remaining dots on the right remain blank. • The data to define a user-defined character is (x x y) bytes. • To print a dot, set the corresponding bit to 1; to not have it print, set to 0. • This command can define different user-defined character patterns for each font. To select the font, use ESC !. • A user-defined character and a downloaded bit image cannot be defined simultaneously. When this command is executed, the downloaded bit image is cleared. • The user-defined character definitions are cleared when: ESC @ or GS * or ESC ? are executed or the printer is reset or the power shut off. 																		
[Default]	Internal character set.																		
[Reference]	ESC % , ESC ?																		
[Example]	<div style="text-align: center;"> <p>18 dots (11 cpi) 13 dots (15 cpi) 10 dots (20 cpi)</p> </div>																		

COMMAND DESCRIPTION

ESC (v nL nH

[Name]	Set relative vertical print position					
[Format]	ASCII	ESC	(v	nL	nH
	Hex	1B	28	76	nL	nH
	Decimal	27	10	118	nL	nH
[Range]	0 ≤ nL ≤ 255					
	0 ≤ nH ≤ 255					
[Description]	Sets the print vertical position based on the current position by using the horizontal or vertical motion unit.					
	<ul style="list-style-type: none"> • This command sets the distance from the current position to [(nL + nH x 256) x (horizontal or vertical motion unit)]. 					
[Notes]	<ul style="list-style-type: none"> • When the starting position is specified by N motion unit to the bottom : $nL + nH \times 256 = N$ When the starting position is specified by N motion unit to the top (negative direction), use the complement of 65536 : $nL + nH \times 256 = 65536 - N$ • The horizontal and vertical motion unit are specified by GS P. • The GS P command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount. • In standard mode, the vertical motion unit is used. 					
[Default]						
[Reference]	GS P					
[Example]						


ESC * m nL nH d1...dk

[Name]	Select bit image mode																																								
[Format]	ASCII	ESC	*	m	nL	nH	d1...dk																																		
	Hex	1B	2A	m	nL	nH	d1...dk																																		
	Decimal	27	42	m	nL	nH	d1...dk																																		
[Range]	m = 0, 1, 32, 33																																								
	0 ≤ nL ≤ 255																																								
	0 ≤ nH ≤ 3																																								
	0 ≤ d ≤ 255																																								
[Description]	Selects a bit image mode using <i>m</i> for the number of dots specified by <i>nL</i> and <i>nH</i> , as follows:																																								
	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2">m</th> <th rowspan="2">Mode</th> <th colspan="2">Vertical direction</th> <th colspan="2">Horizontal direction (*1)</th> </tr> <tr> <th>N. dots</th> <th>DPI</th> <th>DPI</th> <th>N. of Data (k)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>8 dot single density</td> <td>8</td> <td>67</td> <td>100</td> <td>nL + nH x 256</td> </tr> <tr> <td>1</td> <td>8 dot double density</td> <td>8</td> <td>67</td> <td>200</td> <td>nL + nH x 256</td> </tr> <tr> <td>32</td> <td>24 dot single density</td> <td>24</td> <td>200</td> <td>100</td> <td>(nL + nH x 256) x 3</td> </tr> <tr> <td>33</td> <td>24 dot double density</td> <td>24</td> <td>200</td> <td>200</td> <td>(nL + nH x 256) x 3</td> </tr> </tbody> </table>							m	Mode	Vertical direction		Horizontal direction (*1)		N. dots	DPI	DPI	N. of Data (k)	0	8 dot single density	8	67	100	nL + nH x 256	1	8 dot double density	8	67	200	nL + nH x 256	32	24 dot single density	24	200	100	(nL + nH x 256) x 3	33	24 dot double density	24	200	200	(nL + nH x 256) x 3
m	Mode	Vertical direction		Horizontal direction (*1)																																					
		N. dots	DPI	DPI	N. of Data (k)																																				
0	8 dot single density	8	67	100	nL + nH x 256																																				
1	8 dot double density	8	67	200	nL + nH x 256																																				
32	24 dot single density	24	200	100	(nL + nH x 256) x 3																																				
33	24 dot double density	24	200	200	(nL + nH x 256) x 3																																				
[Notes]	<ul style="list-style-type: none"> • The <i>nL</i> and <i>nH</i> commands indicate the number of dots of the bit image in the horizontal direction. The number of dots is calculated using: $nL + nH \times 256$. • If the bit image data input exceeds the number of dots to be printed on a line, the excess data is ignored. • <i>d</i> indicates the bit image data. Set a corresponding bit to 1 to print a dot, or to 0 to not print the dot. • If the value of <i>m</i> is outside the specified range, <i>nL</i> and data following it are processed as normal data. • If the width of the printing area set by GS L and GS W is less than the width required 																																								

COMMAND DESCRIPTION

by the data set using **ESC ***, the excess data are ignored.

- To print the bit image use **LF**, **CR**, **ESC J** or **ESC d**.
- After printing a bit image, the printer returns to normal data processing mode.
- This command is not affected by the emphasized, double-strike, underline (etc.) print modes, except for the upside-down mode.
- The relationship between the image data and the dots to be printed is as follows:
 8-dot bit image 24-dot bit image



[Default]
 [Reference]
 [Example]

ESC - n

[Name] **Turn underline mode on/off**

[Format]	ASCII	ESC	-	n
	Hex	1B	2D	n
	Decimal	27	45	n

[Range] $0 \leq n \leq 2, 48 \leq n \leq 50$

[Description] Turns underline mode on or off, based on the following values of *n*:

- n* = 0, 48 Turns off underline mode
- n* = 1, 49 Turns on underline mode (1-dot thick)
- n* = 2, 50 Turns on underline mode (2-dot thick)

[Notes]

- The printer can underline all characters, but cannot underline the space set by **HT** and right-side character spacing.
- The printer cannot underline 90°/270° rotated characters and white/black inverted characters.
- When underline mode is turned off by setting the value of *n* to 0 or 48, the data which follows is not underlined.
- Underline mode can also be turned on or off by using **ESC !**. Note, however, that the last received command is the effective one.

[Default] n=0
 [Reference] **ESC !**
 [Example]

COMMAND DESCRIPTION

ESC 0

[Name]	Select 1/8-inch line spacing		
[Format]	ASCII	ESC	0
	Hex	1B	30
	Decimal	27	48
[Description]	Selects 1/8-inch line spacing		
[Notes]			
[Default]			
[Reference]	ESC 2, ESC 3		
[Example]			

ESC 2

[Name]	Select 1/6-inch line spacing		
[Format]	ASCII	ESC	2
	Hex	1B	32
	Decimal	27	50
[Description]	Selects 1/6-inch line spacing.		
[Notes]			
[Default]			
[Reference]	ESC 0, ESC 3		
[Example]			

ESC 3 n

[Name]	Set line spacing			
[Format]	ASCII	ESC	3	n
	Hex	1B	33	n
	Decimal	27	51	n
[Range]	$0 \leq n \leq 255$			
[Description]	Sets line spacing to [$n \times$ (vertical or horizontal motion unit)] inches.			
[Notes]	<ul style="list-style-type: none">• The horizontal and vertical motion unit are specified by GS P. Changing the horizontal or vertical motion unit does not affect the current line spacing.• The GS P command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum vertical movement amount.• In standard mode, the vertical motion unit is used.			
[Default]	n = 64 (1/6 inch)			
[Reference]	ESC 0, ESC 2, ESC P			
[Example]				

ESC 4 n

[Name]	Set/reset italic mode			
[Format]	ASCII	ESC	4	n
	Hex	1B	34	n
	Decimal	27	52	n
[Range]	$0 \leq n \leq 1, 48 \leq n \leq 49$			
[Description]	Turns italic mode on or off, based on the following values of <i>n</i> :			

COMMAND DESCRIPTION

n	Function
0, 48	Turns off italic mode
1, 49	Turns on italic mode

- [Notes]
- The printer can print any character in italic mode.
 - When italic mode is turned off by setting the value of *n* to 0 or 48, the data which follows is printed in normal mode.
 - Italic mode can also be turned on or off using **ESC !**. Note, however, that the last received command is the effective one.

[Default] n = 0
 [Reference] **ESC !**
 [Example]

ESC = n

[Name] **Select peripheral device**

[Format] ASCII ESC = n
 Hex 1B 3D n
 Decimal 27 61 n

[Range] 0 ≤ n ≤ 255

[Description] Select the device to which the host computer sends data, using *n* as follows:

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Printer disabled
	On	01	1	Printer enabled
1	-	-	-	Undefined
2	-	-	-	Undefined
3	-	-	-	Undefined
4	-	-	-	Undefined
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Pass-through function disabled
	On	80	128	Pass-through function enabled

- [Notes]
- When the printer is disabled, it ignores all transmitted data until the printer is enabled through this command.

[Default] n = 1
 [Reference]
 [Example]

ESC ? n

[Name] **Cancel user-defined characters**

[Format] ASCII ESC ? n
 Hex 1B 3F n
 Decimal 27 63 n

[Range] 32 ≤ n ≤ 126

[Description] Cancels user-defined characters.

- [Notes]
- This command cancels the pattern defined for the character code specified by *n*. After the user-defined character is cancelled, the corresponding pattern for the internal character is printed.

COMMAND DESCRIPTION

- This command deletes the pattern defined for the specified character code in the font selected by **ESC !**.
- If the user-defined character has not been defined for the specified character code, the printer ignores this command.

[Default]

[Reference]

ESC &, ESC %

[Example]

ESC @

[Name]

Initialize printer

[Format]

ASCII	ESC	@
Hex	1B	40
Decimal	27	64

[Description]

Clears the data in the print buffer and resets the printer mode to that in effect when power was turned on.

[Notes]

- The data in the receiver buffer is not cleared.
- The macro definitions are not cleared.

[Default]

[Reference]

[Example]

ESC D [n1...nk] NUL

[Name]

Set horizontal tab positions

[Format]

ASCII	ESC	D	n1...nk	NUL
Hex	1B	44	n1...nk	00
Decimal	27	68	n1...nk	0

[Range]

$1 \leq n \leq 255$
 $0 \leq k \leq 32$

[Description]

Sets horizontal tab positions

- n specifies the column number for setting a horizontal tab position calculated from the beginning of the line.
- k indicates the total number of horizontal tab positions to be set.

[Notes]

- The horizontal tab position is stored as a value of [character width x n] measured from the beginning of the line. The character width includes the right-side character spacing and double-width characters are set with twice the width of normal characters.
- This command cancels previous tab settings.
- When setting $n = 8$, the print position is moved to column 9, by sending **HT**.
- Up to 32 tab positions ($k = 32$) can be set. Data exceeding 32 tab positions is processed as normal data.
- Send [n] k in ascending order and place a 0 NUL code at the end. When [n] k is less than or equal to the preceding value [n] $k-1$, the setting is complete and the data which follows is processed as normal data.
- **ESC D NUL** cancels all horizontal tab positions.
- The previously specified horizontal tab position does not change, even if the character width is modified.

[Default]

Default tab positions are set at intervals of 8 characters (columns 9, 17, 25, ...) for Font A when the right-side character spacing is 0.

[Reference]

HT

[Example]

ESC E n

[Name]	Turn emphasized mode on/off												
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>ESC</td> <td>E</td> <td>n</td> </tr> <tr> <td>Hex</td> <td>1B</td> <td>45</td> <td>n</td> </tr> <tr> <td>Decimal</td> <td>27</td> <td>69</td> <td>n</td> </tr> </table>	ASCII	ESC	E	n	Hex	1B	45	n	Decimal	27	69	n
ASCII	ESC	E	n										
Hex	1B	45	n										
Decimal	27	69	n										
[Range]	$0 \leq n \leq 255$												
[Description]	Turns emphasized mode on/off. <ul style="list-style-type: none"> • When the LSB of n is 0, the emphasized mode is off. • When the LSB of n is 1, the emphasized mode is on. 												
[Notes]	<ul style="list-style-type: none"> • Only the LSB of n is effective. • ESC ! also turns on and off the emphasized mode. However, the last received command is the effective one. 												
[Default]	$n = 0$												
[Reference]	ESC !												
[Example]													

ESC G n

[Name]	Turn double-strike mode on/off												
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>ESC</td> <td>G</td> <td>n</td> </tr> <tr> <td>Hex</td> <td>1B</td> <td>47</td> <td>n</td> </tr> <tr> <td>Decimal</td> <td>27</td> <td>71</td> <td>n</td> </tr> </table>	ASCII	ESC	G	n	Hex	1B	47	n	Decimal	27	71	n
ASCII	ESC	G	n										
Hex	1B	47	n										
Decimal	27	71	n										
[Range]	$0 \leq n \leq 255$												
[Description]	Turns double-strike mode on or off. <ul style="list-style-type: none"> • When the LSB of n is 0, the double-strike mode is off. • When the LSB of n is 1, the double-strike mode is on. 												
[Notes]	<ul style="list-style-type: none"> • Only the LSB of n is effective. • Printer output is the same in double-strike and emphasized mode. 												
[Default]	$n = 0$												
[Reference]	ESC E												
[Example]													

ESC J n

[Name]	Print and paper feed												
[Format]	<table border="0"> <tr> <td>ASCII</td> <td>ESC</td> <td>J</td> <td>n</td> </tr> <tr> <td>Hex</td> <td>1B</td> <td>4A</td> <td>n</td> </tr> <tr> <td>Decimal</td> <td>27</td> <td>74</td> <td>n</td> </tr> </table>	ASCII	ESC	J	n	Hex	1B	4A	n	Decimal	27	74	n
ASCII	ESC	J	n										
Hex	1B	4A	n										
Decimal	27	74	n										
[Range]	$0 \leq n \leq 255$												
[Description]	Prints the data in the print buffer and feeds the paper [$n \times$ (vertical or horizontal motion unit)] inches.												
[Notes]	<ul style="list-style-type: none"> • After printing has been completed, this command sets the print starting position to the beginning of the line. • The paper feed amount set by this command does not affect the values set by ESC 2 or ESC 3. • The horizontal and vertical motion units are specified by GS P. • GS P can change the vertical (and horizontal) motion unit. However, the value cannot be less than the minimum vertical movement amount. • In standard mode, the vertical motion unit is used. • The maximum paper feed amount is 4095 mm (161 inches). 												
[Default]													

COMMAND DESCRIPTION

[Reference] **GS P**
[Example]

ESC L n

[Name]	Select page mode			
[Format]	ASCII	ESC	L	n
	Hex	1B	4C	n
	Decimal	27	76	n
[Description]	Switches from standard mode to page mode.			
[Notes]	<ul style="list-style-type: none">• This command is enabled only when processed at the beginning of a line in standard mode.• This command has no effect in page mode• After printing by FF is completed or by using ESC S, the printer returns to standard mode.• This command sets the position where data is buffered to the position specified by ESC T within the printing area defined by ESC W.• This command switches the settings for the following commands (in which the values can be set independently in standard mode and page mode) to those for page mode:<ol style="list-style-type: none">1) Set right-side character spacing: ESC SP, FS S2) Select default line spacing: ESC 2, ESC 3• Only value settings is possible for the following commands in page mode; these commands are not executed.<ol style="list-style-type: none">1) Turn 90° clockwise rotation mode on/off: ESC V2) Select justification: ESC a3) Turn upside-down printing mode on/off: ESC {4) Set left margin: GS L5) Set printable area width: GS W• The following command is ignored in page mode:<ol style="list-style-type: none">1) Execute test print: GS (A• The following command is not available in page mode:<ol style="list-style-type: none">1) Print NV bit image: FS p2) Define NV bit image: FS q3) Write to user NV memory: FS g 14) Print raster bit image: GS v 0• The printer returns to standard mode when power is turned on, the printer is reset, or ESC @ is used.			
[Reference]	FF, CAN, ESC FF, ESC S, ESC T, ESC W, GS \$, GS \			
[Example]				

ESC M n

[Name]	Select character font			
[Format]	ASCII	ESC	M	n
	Hex	1B	4D	n
	Decimal	27	77	n
[Range]	n = 0, 1, 48, 49			
[Description]	Selects characters font.			

COMMAND DESCRIPTION

n	Function
0, 48	Character font A (12 x 24) selected
1, 49	Character font B(9 x 17) selected

[Notes]

[Default]

[Reference]

[Example]

ESC R n

[Name] **Select an international character set**

[Format] ASCII ESC R n
 Hex 1B 52 n
 Decimal 27 82 n

[Range] $0 \leq n \leq 10$

[Description] Selects the international character set *n* according to the table below:

	Hex	23	24	40	5B	5C	5D	5E	60	7B	7C	7D	7E
n	Character set												
0	U.S.A.	#	\$	@	[\]	^	`	{		}	~
1	France	#	\$	à	°	ç	§	^	`	è	ù	è	"
2	Germany	#	\$	§	Ä	Ö	Ü	^	`	ä	ö	ü	β
3	United Kingdom	£	\$	@	[\]	^	`	{		}	~
4	Denmark I	#	\$	@	Æ	Ø	Å	^	`	æ	φ	å	~
5	Sweden	#	☒	È	Ä	Ö	Å	Ü	è	ä	ö	å	ü
6	Italy	#	\$	@	°	\	è	^	ù	à	ò	è	ì
7	Spain 1	Pt	\$	@	i	Ñ	¿	^	`	"	ñ	}	~
8	Japan	#	\$	@	[¥]	^	`	{		}	~
9	Norway	#	☒	È	Æ	Ø	Å	Ü	è	æ	φ	å	ü
10	Denmark II	#	\$	È	Æ	Ø	Å	Ü	è	æ	φ	å	ü

[Default] n = 0

[Reference]

[Example]

ESC S

[Name] **Select standard mode.**

[Format] ASCII ESC S
 Hex 1B 53
 Decimal 27 83

[Description] Switches from page mode to standard mode.

COMMAND DESCRIPTION

- [Notes]
- This command is effective only in page mode.
 - Data buffered in page mode are cleared.
 - This command sets the print position to the beginning of the line.
 - The printing area set by **ESC W** are initialized.
 - This command switches the settings for the following commands (in which the values can be set independently in standard mode and page mode) to those for standard mode:
 - 1) Set right-side character spacing: **ESC SP, FS S**
 - 2) Select default line spacing: **ESC 2, ESC 3**
 - The following commands are enabled only to set in standard mode.
 - 1) Set printing area in page mode: **ESC W**
 - 2) Select print direction in page mode: **ESC T**
 - The following commands are ignored in standard mode.
 - 1) Set absolute vertical print position in page mode: **GS \$**
 - 2) Set relative vertical print position in page mode: **GS **
 - Standard mode is selected automatically when power is turned on, the printer is reset, or command **ESC @** is used.

[Default]

[Reference]

FF, ESC FF, ESC L

[Example]

ESC T n

[Name]

Select print direction in page mode.

[Format]

ASCII	ESC	T	n
Hex	1B	54	n
Decimal	27	84	n

[Range]

$0 \leq n \leq 3$
 $48 \leq n \leq 51$

[Description]

Select the print direction and starting position in page mode. n specifies the print direction and starting position as follows :

n	Print direction	Starting position
0, 48	Left to right	Upper left
1,49	Bottom to top	Lower left
2,50	Right to left	Lower right
3,51	Top to bottom	Upper right

[Notes]

- When the command is input in standard mode, the printer executes only internal flag operation. This command does not affect printing in standard mode.
- This command sets the position where data is buffered within the printing area set by **ESC W**.
- Parameters for horizontal or vertical motion units (x or y) differ as follows,depending on the starting position of the printing area:
 - 1) If the starting position is the upper left or lower right of the printing area, data is buffered in the direction perpendicular to the paper feed direction:
 Commands using horizontal motion units: **ESC SP, ESC \$, ESC **
 Commands using vertical motion units: **ESC 3, ESC J, GS \$, GS **
 - 2) If the starting position is the upper right or lower left of the printing area, data is buffered in the paper feed direction:

Commands using horizontal motion units: **ESC 3, ESC J, GS \$, GS **
 Commands using vertical motion units: **ESC SP, ESC \$, ESC **.

Default] $n = 0$
 [Reference] **ESC \$, ESC L, ESC W, ESC \, GS \$, GS P, GS **
 [Example]

ESC V n

[Name] **Set 90° rotated print mode.**
 [Format] ASCII ESC V n
 Hex 1B 56 n
 Decimal 27 86 n
 [Range] $0 \leq n \leq 1$
 $48 \leq n \leq 49$
 [Description] Turns 90° rotation mode on/off. n is used as follows :

n	Function
0, 48	Turns off 90° rotation mode
0,49	Turns on 90° rotation mode

[Notes]

- When underlined mode is turned on, the printer does not underline 90° rotated characters. All the same it's possible select the underline mode.
- Double-width and double-height commands in 90° rotation mode enlarge characters in the opposite directions from double-height *and* double-width commands in normal mode.
- This command is not available in Page mode.
- If this command is entered in Page mode, the printer all the same save the setting.

Default] $n = 0$
 [Reference] **ESC !, ESC -**
 [Example]

ESC W xL xH yL yH dxL dxH dyL dyH

[Name] **Set printing area in page mode.**
 [Format] ASCII ESC W xL xH yL yH dxL dxH dyL dyH
 Hex 1B 57 xL xH yL yH dxL dxH dyL dyH
 Decimal 27 87 xL xH yL yH dxL dxH dyL dyH
 [Range] $0 \leq xL, xH, yL, yH, dxL, dxH, dyL, dyH \leq 255$ (except $dxL = dxH = 0$ or $dyL = dyH = 0$)
 [Description] The horizontal starting position, vertical starting position, printing area width, and printing area height are defined as x_0, y_0, dx (inch), dy (inch), respectively.
 Each setting for the printing area is calculated as follows:
 $x_0 = [(xL + xH \div 256) \div (\text{horizontal motion unit})]$
 $y_0 = [(yL + yH \div 256) \div (\text{vertical motion unit})]$
 $dx = [dxL + dxH \div 256] \div (\text{horizontal motion unit})$
 $dy = [dyL + dyH \div 256] \div (\text{vertical motion unit})$
 The printing area is set as shown in the figure below.

[Notes]

- If this command is input in standard mode, the printer executes only internal flag operation. This command does not affect printing in standard mode.
- If the horizontal or vertical starting position is set outside the printable area, the printer stops command processing and processes the following data as normal data.

COMMAND DESCRIPTION

- If the printing area width or height is set to 0, the printer stops command processing and processes the following data as normal data.
- This command sets the position where data is buffered to the position specified by **ESC T** within the printing area.
- If (horizontal starting position + printing area width) exceeds the printable area, the printing area width is automatically set to (horizontal printable area - horizontal starting position).
- If (vertical starting position + printing area height) exceeds the printable area, the printing area height is automatically set to (vertical printable area - vertical starting position).
- The horizontal and vertical motion unit are specified by **GS P**. Changing the horizontal or vertical motion unit does not affect the current printing area.
- The **GS P** command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of minimum horizontal movement amount.
- Use the horizontal motion unit (x) for setting the horizontal starting position and printing area width, and use the vertical motion unit (y) for setting the vertical starting position and printing area height.
- When the horizontal starting position , vertical starting position, printing area width, and printing area height are defined as X, Y, Dx, and Dy respectively, the printing area is set.

[Default]

[Reference]

[Example]

ESC \ nL nH

[Name] **Set relative print position**

[Format]	ASCII	ESC	\	nL	nH
	Hex	1B	5C	nL	nH
	Decimal	27	92	nL	nH

[Range] $0 \leq nL \leq 255$
 $0 \leq nH \leq 255$

[Description] Sets the print starting position based on the current position by using the horizontal or vertical motion unit.
 Sets the distance from the current position to $[(nL + nH \times 256) \times (\text{horizontal or vertical motion unit})]$.

[Notes]

- Any setting that exceeds the printable area is ignored.
- When the starting position is specified by n motion units to the right:
 $nL + nH \times 256 = n$
- When the starting position is specified by n motion units to the left (negative direction), use the complement of 65536:
 $nL + nH \times 256 = 65536 - n$
- If setting exceeds the printing area width, the left or right margin is set to the default value.
- The horizontal and vertical motion unit are specified by **GS P**.
- **GS P** can change the horizontal (and vertical) motion units. However, the value cannot be less than the minimum horizontal movement amount.
- In standard mode, the horizontal motion unit is used.

[Default]

[Reference] **ESC \$, GS P**

[Example]

ESC a n

[Name]	Select justification								
[Format]	ASCII ESC a n Hex 1B 61 n Decimal 27 97 n								
[Range]	$0 \leq n \leq 2, 48 \leq n \leq 50$								
[Description]	Aligns all data in one line to the specified position. <i>n</i> selects the type of justification as follows: <table border="0" style="margin-left: 40px;"> <tr> <td style="text-align: center;">n</td> <td style="text-align: center;">Justification</td> </tr> <tr> <td style="text-align: center;">0, 48</td> <td style="text-align: center;">Flush left</td> </tr> <tr> <td style="text-align: center;">1, 49</td> <td style="text-align: center;">Centered</td> </tr> <tr> <td style="text-align: center;">2, 50</td> <td style="text-align: center;">Flush right</td> </tr> </table>	n	Justification	0, 48	Flush left	1, 49	Centered	2, 50	Flush right
n	Justification								
0, 48	Flush left								
1, 49	Centered								
2, 50	Flush right								
[Notes]	<ul style="list-style-type: none"> • This command is only enabled when inserted at the beginning of a line. • Lines are justified within the specified printing area. • Spaces set by HT, ESC \$ and ESC \ will be justified according to the previously-entered mode. 								
[Default]	n = 0								
[Reference]									
[Example]									

Flush left	Centered	Flush right
ABC ABCD ABCDE	ABC ABCD ABCDE	ABC ABCD ABCDE

ESC c 3 n

[Name]	Select paper sensor(s) to output paper end signals
[Format]	ASCII ESC c 3 n Hex 1B 63 33 n Decimal 27 99 51 n
[Range]	$0 \leq n \leq 255$
[Description]	Selects the paper sensor(s) to output paper end signals. <ul style="list-style-type: none"> • Each bit of <i>n</i> is used as follows :

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Paper roll end sensor disabled.
	On	01	1	Paper roll end sensor enabled.
1-7	-	-	-	Undefined.

[Notes]	<ul style="list-style-type: none"> • Sensor is switched when executing this command. The paper end signal switching be delayed depending on the receive buffer state. • If bit 0 is on, the paper roll end sensor is selected as the paper sensor outputting paper-end signals. • When all the sensors are disabled, the paper end signal always outputs a paper present status.
[Default]	n = 15
[Reference]	
[Example]	

COMMAND DESCRIPTION

ESC d n

[Name]	Print and feed paper <i>n</i> rows		
[Format]	ASCII	ESC	d n
	Hex	1B	64 n
	Decimal	27	100 n

[Range] $0 \leq n \leq 255$

[Description] Prints the data in the print buffer and feeds the paper *n* rows.

[Notes]

- Sets the print starting position at the beginning of the line.
- This command does not affect the line spacing set by **ESC 2** or **ESC 3**.
- The maximum paper feed amount is 254 rows. Even if a paper feed amount of more than 254 rows is set, the printer feeds the paper only 254 rows.

[Default]

[Reference] **ESC 2, ESC 3**

[Example]

ESC i

[Name]	Total cut		
[Format]	ASCII	ESC	i
	Hex	1B	69
	Decimal	27	105

[Description] This command enables cutter operation. If there is no cutter, a disabling flag is set and any subsequent cut commands will be ignored.

[Notes]

- The printer waits to complete all paper movement commands before it executes a total cut.
- With the SMICE-PS printer, the type of cutter determines whether a total or partial cut is made.
- If you execute the command, disable the parameter "Total Cut", the cut will be partial. If you want to effect a total cut you have to enable the parameter on the Set Up.

[Default]

[Reference]

[Example]

ESC m

[Name]	Partial cut		
[Format]	ASCII	ESC	m
	Hex	1B	6D
	Decimal	27	109

[Description] This command enables cutter operation.

[Notes]

- The printer waits to complete all paper movement commands before it executes a total cut.

[Default]

[Reference]

[Example]

ESC p m t1 t2

[Name]	Generate pulse					
[Format]	ASCII	ESC	p	m	t1	t2
	Hex	1B	70	m	t1	t2
	Decimal	27	112	m	t1	t2
[Range]	m = 0, 1, 48, 49					
	0 ≤ t1 ≤ 255					
	0 ≤ t2 ≤ 255					
[Description]	Outputs the pulse specified by t1 and t2 to connector pin <i>m</i> as follows:					
	<i>m</i>	Connector pin				
	0, 48	Drawer kick-out connector pin 2				
	1, 49	Drawer kick-out connector pin 5				
[Notes]	<ul style="list-style-type: none"> • The pulse ON time is [<i>t1</i> × 2 ms] and the OFF time is [<i>t2</i> × 2 ms]. • If <i>t2</i> < <i>t1</i>, the OFF time is [<i>t1</i> × 2 ms]. 					
[Default]						
[Reference]						
[Example]						

ESC r n

[Name]	Set/reset red printing mode			
[Format]	ASCII	ESC	r	n
	Hex	1B	72	n
	Decimal	27	114	n
[Range]	0 ≤ n ≤ 1, 48 ≤ n ≤ 49			
[Description]	Sets and resets red printing mode.			
	n	Function		
	0, 48	Reset red printing mode		
	1, 49	Set red printing mode		
[Notes]	<ul style="list-style-type: none"> • The printer prints only entire lines in red, not individual characters. • The printer prints red only if enabled (see Setup). 			
[Default]	<i>n</i> = 0			
[Reference]				
[Example]				

ESC t n

[Name]	Select character code table			
[Format]	ASCII	ESC	t	n
	Hex	1B	74	n
	Decimal	27	116	n
[Range]	n = 0, 2, 3, 4, 5, 19, 255			
[Description]	Selects a page <i>n</i> from the character code table, as follows:			

COMMAND DESCRIPTION

n	Page
0	0 (PC437 [U.S.A., Standard Europe])
2	2 (PC850 [Multilingual])
3	3 (PC860 [Portuguese])
4	4 (PC863 [Canadian-French])
5	5 (PC865 [Nordic])
19	19 (PC858 for Euro symbol at position 213)
255	Space page

[Notes]

[Default]

n = 0

[Reference]

See character code tables

[Example]

For printing Euro symbol (•), the command sequence is:
1B, 74, 13, D5

ESC u n

[Name]

Transmit peripheral device status

[Format]

ASCII ESC u n

Hex 1B 75 n

Decimal 27 117 n

[Range]

n = 0, 48

[Description]

Transmits the status of connector pin n upon receiving this command, using n as follows:

n	Connector Pin
0, 48	Drawer kick-out connector pin 3

[Notes]

- This command is executed when the data is processed in the data buffer. There may be a time lag between receiving the command and transmitting the status, depending on data buffer status.
- When the connector is not used, the bit 0 value is always 1.
- The status to be transmitted is shown in the table below:

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Pin 3 low level
	On	01	1	Pin 3 high level
1	-	-	-	Undefined
2	-	-	-	Undefined
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

[Default]

[Reference]

DLE EOT, GS r

See drawer connector

[Example]

ESC v

[Name] **Transmit paper sensor status**

[Format] ASCII ESC v
 Hex 1B 76
 Decimal 27 118

[Description] When this command is received, transmit the current status of the paper sensor.

[Notes] • This command is executed immediately, even when the data buffer is full (Busy).
 The status to be transmitted is shown in the table below:

Bit	Off/On	Hex	Decimal	Function
0,1	Off	00	0	Not used
	On	03	3	Not used
2,3	Off	00	0	Paper-end sensor: Paper present
	On	(0C)	(12)	Paper-end sensor: Paper not present
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

[Default]

[Reference] **DLE EOT**

[Example]

ESC { n

[Name] **Turn upside-down printing mode on/off**

[Format] ASCII ESC { n
 Hex 1B 7B n
 Decimal 27 123 n

[Range] $0 \leq n \leq 255$

[Description] Turns upside-down printing mode on or off.


- When the LSB of n is 0, the upside-down printing mode is off.
- When the LSB of n is 1, the upside-down printing mode is on.

[Notes] • Only the LSB of n is effective.
 • This command is valid only if entered at the beginning of a line.
 • In upside-down printing mode, the printer rotates the line to be printed 180° and then prints it.

[Default] $n = 0$

[Reference]

[Example]



COMMAND DESCRIPTION

ESC { } n

[Name]	Set/cancel cpi mode
[Format]	ASCII ESC ⊥ n Hex 1B C1 n Decimal 27 193 n
[Range]	$0 \leq n \leq 1, 48 \leq n \leq 49$
[Description]	Sets cpi mode based on the following values of <i>n</i> :

n	Function
0, 48	Font A = 11 cpi Font B = 15 cpi
1, 49	Font A = 15 cpi Font B = 20 cpi

[Default]	n = 0
[Reference]	ESC !
[Example]	

ESC { } n xH xL yH yL

[Name]	Print graphic.
[Format]	ASCII ESC { } n xH xL yH yL Hex 1B FA n xH xL yH yL Decimal 27 250 n xH xL yH yL
[Range]	$0 \leq n \leq 3$ $0 \leq xH, xL, yH, yL \leq 255$
[Description]	Prints graphic logo from flash or current graphic page located in ram. <i>n</i> selects the graphic source as follows:

n	Function
0	Print graphic page from ram (used at the moment)
1	Print logo 1 from flash

The maximum printable vertical dimension *dhmax* is :

- if paper width is 112mm $dhmax = 630$
- if paper width is 80mm $dhmax = 819$

$xL + xH \times 256$ specifies the starting dotline ($1 \div dhmax$).
 $yL + yH \times 256$ specifies the number of lines to print.

[Notes]	<ul style="list-style-type: none"> • If $(xL + (xH \times 256)) > dhmax$ the printer does not execute the command. • If $(xL + (xH \times 256) + yL + (yH \times 256)) > dhmax$ the printer prints only $dhmax - xL + (xH \times 256) + 1$ dotline.
---------	--

[Default]	
[Reference]	ESC ³, ESC ², ESC
[Example]	To print from ram bank dotline 100 to dotline 299, send: 1BH FAH 00H 00H 64H 00H C7H

ESC { } nL nH

[Name]	Transmit graphic page to communication port				
[Format]	ASCII	ESC	{ }	nL	nH
	Hex	1B	FB	nL	nH
	Decimal	27	251	nL	nH
[Description]	Transmits $[nL + (nH \times 256)]$ word of graphic page used at the moment to the communication port.				
[Default]					
[Reference]	ESC³, ESC², ESC¹				
[Example]					

ESC { } n

[Name]	Transfer flash bank into graphic page			
[Format]	ASCII	ESC	{ }	n
	Hex	1B	FC	n
	Decimal	27	252	n
[Range]	$1 \leq n \leq 3$			
[Description]	Transfers flash bank into graphic page used at the moment (65520 bytes). <i>n</i> selects the flash bank as follows:			

n	Function
1	Transfers flash bank logo 1 into ram

[Notes]	
[Default]	
[Reference]	ESC¹, ESC², ESC³
[Example]	

ESC { } nL nH

[Name]	Receive graphic page from communication port				
[Format]	ASCII	ESC	{ }	nL	nH
	Hex	1B	FD	nL	nH
	Decimal	27	253	nL	nH
[Range]	$0 \leq nL, nH \leq 255$				
[Description]	Receives $[nL + (nH \times 256)]$ words from the port and puts them into the ram bank.				
[Notes]	<ul style="list-style-type: none"> • The number of data bytes received is $[nL + (nH \times 256)] \times 2$. • Each word is first received as MSByte and then as LSByte. • If $[nL + (nH \times 256)]$ is greater than 32768, the data which follows is processed as normal data. • The flash bank dimensions for the graphic print are : <ul style="list-style-type: none"> with 112mm paper width have 832 horizontals dots (104 bytes/dot line) x 630 verticals dots (65520 bytes). with 80mm paper width have 640 horizontals dots (80 bytes/dot line) x 819 verticals dots (65520 bytes). 				
[Default]					
[Reference]	ESC¹, ESC³, ESC²				
[Example]					

COMMAND DESCRIPTION

ESC | n

[Name]	Transfer graphic page into flash bank			
[Format]	ASCII	ESC		n
	Hex	1B	FE	n
	Decimal	27	254	n
[Range]	1 ≤ n ≤ 3			
[Description]	Transfers the graphic page used at the moment into the flash bank (65520 bytes). n selects the bank as follows:			

n	Function
1	Transfers graphic page used at the moment into flash bank logo 1

[Notes]	
[Default]	
[Reference]	ESC ·, ESC ², ESC ³
[Example]	

ESC { }

[Name]	Print data in page mode		
[Format]	ASCII	ESC	{ }
	Hex	1B	0C
	Decimal	27	12
[Description]	In page mode, prints all buffered data in the printing area collectively.		
[Notes]	<ul style="list-style-type: none"> • This command is enabled only in page mode. • After printing, the printer does not clear the buffered data, setting values for ESC T and ESC W, and the position for buffering character data. 		
[Default]			
[Reference]	FF, ESC L, ESC S		
[Example]			

FS p n m

[Name]	Print a NV bit image.				
[Format]	ASCII	FS	p	n	m
	Hex	1C	70	n	m
	Decimal	28	112	n	m
[Range]	1 ≤ n ≤ 255				
	0 ≤ m ≤ 3, 48 ≤ m ≤ 51				
[Description]	Print a NV bit image n using the mode specified by m :				

m	Mode
0, 48	Normal
1, 49	Double-width
2, 50	Double-height
3, 51	Quadruple

[Notes]	<ul style="list-style-type: none"> • n is the number of the NV bit image (defined using the FS q command). • m specifies the bit image. • NV bit image means a bit image which is defined in a non-volatile memory by FS q and
---------	---

printed by **FS p**.

- This command is not effective when the specified NV bit image has not been defined.
- This command is available only when paper roll is selected using **ESC c 0**.
- In standard mode, this command is effective only when there is no data in the print buffer.
- In page mode, this command is not effective.
- This command is not affected by print modes (emphasized, double-strike, underline, character size, white/black reverse printing, or 90° rotated characters, etc.), except upside-down printing mode.
- If the printing area width set by **GS L** and **GS W** for the NV bit image is less than one vertical line, the following processing is executed only on the line in question. However, in NV bit image mode, one vertical line means 1 dot (one half dot for slip paper) in normal mode ($m=0$, 48) and in double-height mode ($m=2$, 50), and it means 2 dots (two half dots for slip paper) in double-width mode ($m=1$, 49) and in quadruple mode ($m=3$, 51).
 - 1) The printing area width is extended to the right in NV bit image mode up to one line vertically. In this case, printing does not exceed the printable area.
 - 2) If the printing area width cannot be extended by one line vertically, the left margin is reduced to accommodate one line vertically.
- If the downloaded bit image to be printed exceeds one line, the excess data is not printed.
- This command feeds dots (for the height n of the NV bit image) in normal and double-width modes, and (for the height $n \times 2$ of the VN bit image) in double-height and quadruple modes, regardless of the line spacing specified by **ESC 2** or **ESC 3**.
- After printing the bit image, this command sets the print position to the beginning of the line and processes the data that follows as normal data.

[Default]

[Reference]

FS q

[Example]

FS q n [xL xH yL yH d1...dk]1...[xL xH yL yH d1...dk]n

[Name]

Define a NV bit image.

[Format]

ASCII FS q n [xL xH yL yH d1...dk]1...[xL xH yL yH d1...dk]n
 Hex 1C 71 n [xL xH yL yH d1...dk]1...[xL xH yL yH d1...dk]n
 Decimal 28 113 n [xL xH yL yH d1...dk]1...[xL xH yL yH d1...dk]n [Range]

$1 \leq n \leq 255$

$0 \leq xL \leq 255$
 $0 \leq xH \leq 3$ (when $1 \leq (xL + xH \times 256) \leq 1023$)
 $0 \leq yL \leq 1$ (when $1 \leq (yL + yH \times 256) \leq 288$)
 $0 \leq d \leq 255$
 $k = (xL + xH \times 256) \times (yL + yH \times 256) \times 8$
 Total defined data area = 3M bits (384K bytes)

[Description]

Define the NV bit image specified by n .

- n specifies the number of the defined NV bit image.
- xL, xH specifies $(xL + xH \times 256) \times 8$ dots in the horizontal direction for the NV bit image you are defining.
- yL, yH specifies $(yL + yH \times 256) \times 8$ dots in the vertical direction for the NV bit image you are defining.

[Notes]

- Frequent write command execution may cause damage the NV memory. Therefore, it is recommended to write the NV memory 10 times or less a day.
- The printer executes a hardware reset after the procedure to place the image into the

COMMAND DESCRIPTION

non-volatile memory. Therefore, user-defined characters, downloaded bit images, and macros should be defined only after completing this command. The printer clears the receive and print buffers and resets the mode to the mode that was in effect at power on.

- During processing this command, the printer is in BUSY when writing the data to the user NV memory and stops receiving data. Therefore it is prohibited to transmit the data including the real-time commands during the execution of this command.
- This command cancels all NV bit images that have already been defined by this command. The printer can not redefine only one of several data definitions previously defined. In this case, all data needs to be sent again.
- From the beginning of the processing of this command till the finish of hardware reset, mechanical operations (including initializing the position of the printer head when the cover is open, paper feeding by using the PAPER FEED button, etc.) cannot be executed.
- NV bit image means a bit image which is defined in a non-volatile memory by **FS q** and printed by **FS p**.
- In standard mode, this command is effective only when processed at the beginning of the line.
- In page mode, this command is not effective.
- This command is effective when 7 bytes <FS~yH> is processed as a normal value.
- When the amount of data exceeds the capacity left in the range defined by xL, xH, yL, yH, the printer processes xL, xH, yL, yH out of the defined range.
- In the first group of NV bit images, when any of the parameters xL, xH, yL, yH is out of the definition range, this command is disabled.
- In groups of NV bit images other than the first one, when the printer processes xL, xH, yL, yH out of the defined range, it stops processing this command and starts writing into the non-volatile images. At this time, NV bit images that haven't been defined are disabled (undefined), but any NV bit images before that are enabled.
- The d indicates the definition data. In data (d) a 1 bit specifies a dot to be printed and a 0 bit specifies a dot not to be printed.
- This command defines n as the number of a NV bit image. Numbers rise in order from NV bit image 01H. Therefore, the first data group [xL xH yL yH d1...dk] is NV bit image 01H, and the last data group [xL xH yL yH d1...dk] is NV bit image n. The total agrees with the number of NV bit images specified by command **FS p**.
- A definition data of a NV bit image consists of [xL xH yL yH d1...dk]. Therefore, when only one NV bit image is defined, n=1.
- The printer processes a data group [xL xH yL yH d1...dk] once.
- The printer uses $([data: (xL + xH \times 256) \times (yL + yH \times 256) \times 8] + [header :4])$ bytes of non-volatile memory.
- The definition area in this printer is a maximum of 3M bits (384K bytes). This command can define several NV bit images, but cannot define a bit image data whose total capacity [bit image data + header] exceeds 3M bytes (384K bytes).
- The printer is busy immediately before writing into non-volatile memory.
- The printer does not transmit ASB status and executes status detection during processing of this command even when ASB is specified.
- This command defines NV bit image printing on a paper roll without being affected by the sheet setting selected in **ESC c 1**.
- When this command is received during macro definition, the printer ends macro definition, and begins executing this command.
- Once a NV bit image is defined, it is not erased by executing **ESC @**, reset, and power off.
- This command executes only definition of a NV bit image and does not execute printing. Printing of the NV bit image is executed by the **FS p** command.


[Default]

[Reference]

FS p

[Example]

When $xL = 64$, $xH = 0$, $yL = 96$, $yH = 0$



GS ! n

[Name]

Select character size

[Format]

ASCII	GS	!	n
Hex	1D	21	n
Decimal	29	33	n

[Range]

$0 \leq n \leq 255$

[Description]

Selects character height and width, as follows:

- Bits 0 to 3: to select character height (see table 2).
- Bits 4 to 7: to select character width (see table 1).

COMMAND DESCRIPTION

Table 1 Select Character Width

Hex	Decimal	Width
00	0	1 (normal)
10	16	2 (width = 2x)
20	32	3 (width = 3x)
30	48	4 (width = 4x)
40	64	5 (width = 5x)
50	80	6 (width = 6x)
60	96	7 (width = 7x)
70	112	8 (width = 8x)

Table 2 Select character height

Hex	Decimal	Height
00	0	1 (normal)
01	1	2 (height = 2x)
02	2	3 (height = 3x)
03	3	4 (height = 4x)
04	4	5 (height = 5x)
05	5	6 (height = 6x)
06	6	7 (height = 7x)
07	7	8 (height = 8x)

- [Notes]
- This command is effective for all characters (except HRI characters).
 - If n falls outside the defined range, this command is ignored.
 - Characters enlarged to different heights on the same line are aligned at the baseline or topline (see **GS ~**).
 - **ESC !** can also be used to select character size. However, the setting of the last received command is the effective one.

[Default] $n = 0$

[Reference] **ESC !**

[Example]

GS \$ nL nH

[Name] **Set absolute vertical print position in page mode**

[Format]	ASCII	GS	\$	nL	nH
	Hex	1D	24	nL	nH
	Decimal	29	36	nL	nH

[Range] $0 \leq nL \leq 255, 0 \leq nH \leq 255$

[Description]

- Set the absolute vertical print starting position for buffer character data in page mode.
- This command sets the absolute print position to $[(nL + nH \times 256) \times (\text{vertical or horizontal motion unit})]$ inches.

- [Notes]
- This command is effective only in page mode.
 - If the $[(nL + nH \times 256) \times (\text{vertical or horizontal motion unit})]$ exceeds the specified printing area, this command is ignored.
 - The horizontal starting buffer position does not move.
 - The reference starting position is that specified by **ESC T**.
 - This command operates as follows, depending on the starting position of the printing area specified by **ESC T**:
 - 1) When the starting position is set to the upper left or lower right, this command sets the absolute position in the vertical direction.
 - 2) When the starting position is set to the upper right or lower left, this command sets the absolute position in the horizontal direction.
 - The horizontal and vertical motion unit are specified by **GS P**.
 - The **GS P** command can change the horizontal and vertical motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of the minimum horizontal movement amount.

[Reference] **ESC \$, ESC T, ESC W, ESC \, GS P, GS **

GS * x y d1..d(x x y x 8)

[Name] **Define downloaded bit image**

[Format] ASCII GS * x y d1...d(x x y x 8)
 Hex 1D 2A x y d1...d(x x y x 8)
 Decimal 29 42 x y d1...d(x x y x 8)


[Range] $1 \leq x \leq 255$
 $1 \leq y \leq 48$
 $x \times y \leq 1536$
 $0 \leq d \leq 255$

[Description] Defines a downloaded bit image using the number of dots specified by x and y.

- x specifies the number of dots in the horizontal direction.
- y specifies the number of dots in the vertical direction.

[Notes]

- The number of dots in the horizontal direction is $x \times 8$, in the vertical direction it is $y \times 8$.
- If $x \times y$ is out of the specified range, this command is disabled.
- The d indicates bit-image data. Data (d) specifies a bit printed to 1 and not printed to 0.
- The downloaded bit image definition is cleared when:
 - 1) **ESC @** is executed.
 - 2) **ESC &** is executed.
 - 3) **FS q** is executed.
- Printer is reset or the power is turned off.
- The following figure shows the relationship between the downloaded bit image and the printed data.



[Reference] **GS **

[Example]

COMMAND DESCRIPTION

GS / m

[Name]	Print downloaded bit image			
[Format]	ASCII	GS	/	m
	Hex	1D	2F	m
	Decimal	29	47	m
[Description]	Prints a downloaded bit image using the mode specified by m. <i>m</i> selects a mode from the table below :			

m	Mode
0,48	Normal
1, 49	Double-width
2, 50	Double-height
3, 51	Quadruple

[Notes]	<ul style="list-style-type: none">• This command is ignored if a downloaded bit image has not been defined.• In standard mode, this command is effective only when there is no data in the print buffer.• This command has no effect in the print modes (emphasized, underline, character size, or white/black reverse printing), except for upside-down printing mode.• If the downloaded bit-image to be printed exceeds the printable area, the excess data is not printed.• If the printing area width set by GS L and GS W is less than one line in vertical, the following processing is performed only on the line in question:<ol style="list-style-type: none">1) The printing area width is extended to the right up to one line in vertical. In this case, printing does not exceed the printable area.2) If the printing area width cannot be extended by one line in vertical, the left margin is reduced to accommodate one line in vertical.
[Reference]	GS *
[Example]	

GS :

[Name]	Start/end macro definition		
[Format]	ASCII	GS	:
	Hex	1D	3A
	Decimal	29	58
[Description]	Starts or ends macro definition.		
[Notes]	<ul style="list-style-type: none">• Macro definition starts when this command is received during normal operation.• When GS ^ is received during macro definition, the printer ends macro definition and clears all definitions.• Macros are not defined when power is turned on to the machine.• Macro content is not cancelled by the ESC @ command. Therefore, ESC @ may be included in the content of macro definitions.• If the printer receives GS : a second time after previously receiving GS :, the printer remains in macro undefined status.• The contents of the macro can be defined up to 1024 bytes. If the macro definition exceeds 1024 bytes, excess data is not stored.		
[Default]			
[Reference]	GS ^		
[Example]			

GS B n

[Name]	Turn white/black reverse printing mode on/off															
[Format]	<table border="0" style="width: 100%;"> <tr> <td style="width: 20%;">ASCII</td> <td style="width: 10%;">GS</td> <td style="width: 10%;">B</td> <td style="width: 10%;">n</td> <td style="width: 50%;"></td> </tr> <tr> <td>Hex</td> <td>1D</td> <td>42</td> <td>n</td> <td></td> </tr> <tr> <td>Decimal</td> <td>29</td> <td>66</td> <td>n</td> <td></td> </tr> </table>	ASCII	GS	B	n		Hex	1D	42	n		Decimal	29	66	n	
ASCII	GS	B	n													
Hex	1D	42	n													
Decimal	29	66	n													
[Range]	$0 \leq n \leq 255$															
[Description]	<p>Turns white/black reverse printing mode on or off.</p> <ul style="list-style-type: none"> • When the LSB of n is 0, white/black reverse printing is turned off. • When the LSB of n is 1, white/black reverse printing is turned on. 															
[Notes]	<ul style="list-style-type: none"> • Only the LSB of n is effective. • This command is available for both built-in and user-defined characters. • This command does not affect bit image, downloaded bit image, bar code, HRI characters and spacing skipped by HT, ESC \$ and ESC \. • This command does not affect white space between lines. • White/black reverse mode has a higher priority than underline mode. Even if underline mode is on, it will be disabled (but not cancelled) when white/black reverse mode is selected. 															
[Default]	$n = 0$															
[Reference]																
[Example]																

GS C 0 n m

[Name]	Select counter print mode																					
[Format]	<table border="0" style="width: 100%;"> <tr> <td style="width: 20%;">ASCII</td> <td style="width: 10%;">GS</td> <td style="width: 10%;">C</td> <td style="width: 10%;">0</td> <td style="width: 10%;">n</td> <td style="width: 10%;">m</td> <td style="width: 30%;"></td> </tr> <tr> <td>Hex</td> <td>1D</td> <td>43</td> <td>30</td> <td>n</td> <td>m</td> <td></td> </tr> <tr> <td>Decimal</td> <td>29</td> <td>67</td> <td>48</td> <td>n</td> <td>m</td> <td></td> </tr> </table>	ASCII	GS	C	0	n	m		Hex	1D	43	30	n	m		Decimal	29	67	48	n	m	
ASCII	GS	C	0	n	m																	
Hex	1D	43	30	n	m																	
Decimal	29	67	48	n	m																	
[Range]	$0 \leq n \leq 5$ $m = 0, 1, 2, 48, 49, 50$																					
[Description]	<p>Selects a print mode for the serial number counter.</p> <ul style="list-style-type: none"> • n specifies the number of digits to be printed as follows: when $n = 0$, the printer prints the actual digits indicated by the numeric value. when $n = 1$ to 5, the command sets the number of digits to be printed. • m specifies the printing position within the entire range of printed digits as follows: 																					
	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="width: 10%;">m</th> <th style="width: 30%;">Printing position</th> <th style="width: 60%;">Processing of digits less than those specified</th> </tr> </thead> <tbody> <tr> <td>0, 48</td> <td>Flush right</td> <td>Adds spaces to the left</td> </tr> <tr> <td>1, 49</td> <td>Flush right</td> <td>Adds a '0' to the left</td> </tr> <tr> <td>2, 50</td> <td>Flush left</td> <td>Adds spaces to the right</td> </tr> </tbody> </table>	m	Printing position	Processing of digits less than those specified	0, 48	Flush right	Adds spaces to the left	1, 49	Flush right	Adds a '0' to the left	2, 50	Flush left	Adds spaces to the right									
m	Printing position	Processing of digits less than those specified																				
0, 48	Flush right	Adds spaces to the left																				
1, 49	Flush right	Adds a '0' to the left																				
2, 50	Flush left	Adds spaces to the right																				
[Notes]	<ul style="list-style-type: none"> • If n or m is out of the defined range, the previously set print mode is not changed. • If $n = 0$, m is not applicable. 																					
[Default]	$n = 0, m = 0$																					
[Reference]	GS C 1, GS C 2, GS C ;, GS c																					
[Example]	<table border="0" style="width: 100%;"> <tr> <td style="width: 33%;">$n = 3, m = 0$</td> <td style="width: 33%;">$n = 3, m = 1$</td> <td style="width: 33%;">$n = 3, m = 2$</td> </tr> <tr> <td style="text-align: center;">□□1</td> <td style="text-align: center;">001</td> <td style="text-align: center;">1□□</td> </tr> </table> <p>□ indicates a space</p>	$n = 3, m = 0$	$n = 3, m = 1$	$n = 3, m = 2$	□□1	001	1□□															
$n = 3, m = 0$	$n = 3, m = 1$	$n = 3, m = 2$																				
□□1	001	1□□																				

COMMAND DESCRIPTION

GS C 1 aL aH bL bH n r

[Name]	Select count mode (A).																														
[Format]	<table border="0" style="width: 100%;"> <tr> <td style="width: 15%;">ASCII</td> <td style="width: 10%;">GS</td> <td style="width: 10%;">C</td> <td style="width: 10%;">1</td> <td style="width: 10%;">aL</td> <td style="width: 10%;">aH</td> <td style="width: 10%;">bL</td> <td style="width: 10%;">bH</td> <td style="width: 10%;">n</td> <td style="width: 10%;">r</td> </tr> <tr> <td>Hex</td> <td>1D</td> <td>43</td> <td>31</td> <td>aL</td> <td>aH</td> <td>bL</td> <td>bH</td> <td>n</td> <td>r</td> </tr> <tr> <td>Decimal</td> <td>29</td> <td>67</td> <td>49</td> <td>aL</td> <td>aH</td> <td>bL</td> <td>bH</td> <td>n</td> <td>r</td> </tr> </table>	ASCII	GS	C	1	aL	aH	bL	bH	n	r	Hex	1D	43	31	aL	aH	bL	bH	n	r	Decimal	29	67	49	aL	aH	bL	bH	n	r
ASCII	GS	C	1	aL	aH	bL	bH	n	r																						
Hex	1D	43	31	aL	aH	bL	bH	n	r																						
Decimal	29	67	49	aL	aH	bL	bH	n	r																						
[Range]	<p>$0 \leq aL, aH \leq 255$</p> <p>$0 \leq bL, bH \leq 255$</p> <p>$0 \leq n, r \leq 255$</p>																														
[Description]	<p>Selects a count mode for the serial number counter.</p> <ul style="list-style-type: none"> • <i>aL</i>, <i>aH</i> or <i>bL</i>, <i>bH</i> specify the counter range. • <i>n</i> indicates the unit amount when counting up or down. • <i>r</i> indicates the repetition number when the counter value is fixed. 																														
[Notes]	<ul style="list-style-type: none"> • Count-up mode is specified when: $[aL + (aH \times 256)] < [bL + (bH \times 256)]$ and $n \neq 0$ and $r \neq 0$ • Count-down mode is specified when: $[aL + (aH \times 256)] > [bL + (bH \times 256)]$ and $n \neq 0$ and $r \neq 0$ • Counting stops when: $[aL + (aH \times 256)] = [bL + (bH \times 256)]$ or $n = 0$ or $r = 0$ • Setting the count-up mode, the minimum counter value is $[aL + (aH \times 256)]$ and the maximum value is $[bL + (bH \times 256)]$. If the counting up reaches a value that exceeds the maximum, it resets to the minimum value. • Setting the count-down mode, the maximum counter value is $[aL + (aH \times 256)]$ and the minimum value is $[bL + (bH \times 256)]$. If the counting down reaches a value less than the minimum, it resets to the maximum value. • When this command is executed, the internal count that indicates the repetition number specified by <i>r</i> is cleared. 																														
[Default]	$aL = 1, aH = 0, bL = 255, bH = 255, n = 1, r = 1$																														
[Reference]	GS C 0, GS C 2, GS C ;, GS c																														
[Example]																															

GS \ nL nH

[Name]	Set relative vertical print position in page mode															
[Format]	<table border="0" style="width: 100%;"> <tr> <td style="width: 15%;">ASCII</td> <td style="width: 10%;">GS</td> <td style="width: 10%;">\</td> <td style="width: 10%;">nL</td> <td style="width: 10%;">nH</td> </tr> <tr> <td>Hex</td> <td>1D</td> <td>5C</td> <td>nL</td> <td>nH</td> </tr> <tr> <td>Decimal</td> <td>29</td> <td>92</td> <td>nL</td> <td>nH</td> </tr> </table>	ASCII	GS	\	nL	nH	Hex	1D	5C	nL	nH	Decimal	29	92	nL	nH
ASCII	GS	\	nL	nH												
Hex	1D	5C	nL	nH												
Decimal	29	92	nL	nH												
[Range]	$0 \leq nL \leq 255, 0 \leq nH \leq 255$															
[Description]	<ul style="list-style-type: none"> • Sets the relative vertical print starting position from the current position in page mode. • This command sets the distance from the current position to $[(nL + nH \times 256) \times \text{vertical or horizontal motion unit}]$ inches. 															
Notes]	<ul style="list-style-type: none"> • This command is ignored unless page mode is selected. • When <i>N</i> is specified to the movement downward: $nL + nH \times 256 = N$ • When <i>N</i> is specified to the movement upward (the negative direction), use the complement of 65536. $nL + nH \times 256 = 65536 - N$ • When <i>N</i> is specified to the movement upward: $nL + nH \times 256 = 65536 - N$ • Any setting that exceeds the specified printing area is ignored. • This command function as follows, depending on the print starting position set by ESC T: 1) When the starting position is set to the upper left or lower right of the printing, the 															

vertical motion unit (y) is used.

2) When the starting position is set to the upper right or lower left of the printing area, the horizontal motion unit (x) is used.

- The horizontal and vertical motion unit are specified by **GS P**.
- The **GS P** command can change the horizontal (and vertical) motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of the minimum horizontal movement amount.

[Reference]

ESC \$, ESC T, ESC W, ESC \, GS \$, GS P

[Example]

GS C 2 nL nH

[Name]

Set counter

[Format]

ASCII	GS	C	2	nL	nH
Hex	1D	43	32	nL	nH
Decimal	29	67	50	nL	nH

[Range]

$0 \leq nL, nH \leq 255$

[Description]

Sets the serial number counter value.

- *nL* and *nH* determine the value of the serial number counter set by $[nL + (nH \times 256)]$.

[Notes]

- In count-up mode, if the counter value specified by this command goes out of the counter operation range specified by **GS C 1** or **GS C**; it is forced to convert to the minimum value through **GS c**.
- In count-down mode, if the counter value specified by this command goes out of the counter operation range specified by **GS C 1** or **GS C**; it is forced to convert to the maximum value through **GS c**.

[Default]

nL = 1, *nH* = 0

[Reference]

GS C 0, GS C 1, GS C ;, GS c

[Example]

GS C ; sa ; sb ; sn ; sr ; sc ;

[Name]

Select count mode (B)

[Format]

ASCII	GS	C	;	sa	;	sb	;	sn	;	sr	;	sc	;
Hex	1D	43	3B	sa	3B	sb	3B	sn	3B	sr	3B	sc	3B
Decimal	29	67	59	sa	59	sb	59	sn	59	sr	59	sc	59

[Range]

$0 \leq sa, sb, sc \leq 65535$

$0 \leq sn, sr \leq 255$

These values are all character strings.

[Description]

Selects a count mode for the serial number counter and specifies the value of the counter.

- *sa*, *sb*, *sn*, *sr* and *sc* are all displayed as ASCII characters using codes from '0' to '9'.
- *sa* and *sb* specify the counter range.
- *sn* indicates the unit amount for counting up or down.
- *sr* indicates the repetition number when the counter value is fixed.
- *sc* indicates the counter value.

[Notes]

- Count-up mode is specified when:
 $sa < sb$ and $sn \neq 0$ and $sr \neq 0$
- Count-down mode is specified when:
 $sa > sb$ and $sn \neq 0$ and $sr \neq 0$
- Counting stops when:
 $sa = sb$ or $sn = 0$ or $sr = 0$
- In setting count-up mode, the minimum value of the counter is *sa* and the maximum

COMMAND DESCRIPTION

value is *sb*. If counting up reaches a value exceeding the maximum, it resets to the minimum value. If the counter value set by *sc* is outside the counter operation range, the counter value is forced to convert to the minimum value by executing **GS c**.

- In setting count-down mode, the maximum value of the counter is *sa* and the minimum value is *sb*. If counting down reaches a value less than the minimum, it resets to the maximum value. If the counter value set by *sc* is outside the counter operation range, the counter value is forced to convert to the maximum value by executing **GS c**.
- Parameters *sa* to *sc* can be omitted. If omitted, they remain unchanged.
- Parameters *sa* to *sc* cannot contain characters other than '0' to '9'.

[Default] *sa* = 1, *sb* = 65535, *sn* = 1, *sr* = 1, *sc* = 1
 [Reference] **GS C 0, GS C 2, GS C 1, GS c**
 [Example]

GS H n

[Name] **Select printing position of Human Readable Interpretation (HRI) characters**

[Format] ASCII GS H n
 Hex 1D 48 n
 Decimal 29 72 n

[Range] $0 \leq n \leq 3, 48 \leq n \leq 51$

[Description] Selects the printing position of HRI characters when printing bar codes.
n selects the printing positions as follows:

n	Function
0, 48	Not printed
1, 49	Above the bar code
2, 50	Below the bar code
3, 51	Both above the below the bar code

[Notes] • HRI characters are printed using the font specified by **GS f**.

[Default] *n* = 0

[Reference] **GS f, GS k**

[Example]

GS I n (ONLY WITH SERIAL INTERFACE)

[Name] **Transmit printer ID**

[Format] ASCII GS I n
 Hex 1D 49 n
 Decimal 29 73 n

[Range] $1 \leq n \leq 4, 49 \leq n \leq 52$

[Description] Transmits the printer ID specified by *n* follows:

n	Printer ID	Specification
1, 49	Printer model ID	30H
2, 50	Type ID	See table below
3, 51	ROM version ID	Depends on ROM version (4 character)
4, 52	Printer version ID	See table below

COMMAND DESCRIPTION

n = 2, Type ID

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	2-byte character codes not supported
1	Off	00	0	Autocutter not supplied
				Autocutter supplied
2	Off	00	0	Thermal paper w/o label
	On	04	4	Thermal paper w/label
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

- [Notes]
- When the DTR/DSR command is selected, the printer only transmits 1 byte (printer ID) following confirmation that the host is ready to receive data. If the host is not ready, the printer waits until it is ready.
 - When the XON/XOFF command is selected, the printer only transmits 1 byte (printer ID) without confirmation that the host is ready to receive data.
 - This command is executed when the data is processed in the data buffer. Therefore, there could be a time lag between command reception and data transmission, depending on data buffer status.

[Default]

[Reference]


[Example]

GS L nL nH

[Name]	Set left margin				
[Format]	ASCII	GS	L	nL	nH
	Hex	1D	4C	nL	nH
	Decimal	29	76	nL	nH

[Range] $0 \leq nL, nH \leq 255$

[Description] Sets the left margin.
 • The left margin is set to $[(nL + nH \times 256) \times (\text{horizontal motion unit})]$ inches.



- [Notes]
- This command is enabled only if set at the beginning of the line.
 - If the setting exceeds the printable area, the maximum value of the printable area is used.
 - If the left margin + printing area width is greater than the printable area, the printing area width is set at maximum value.
 - The horizontal and vertical motion unit are specified by **GS P**. Changing the horizontal or vertical motion unit does not affect the current left margin.
 - The **GS P** command can change the horizontal (and vertical) motion unit.
 - However, the value cannot be less than the minimum horizontal movement amount and it must be in even units of the minimum horizontal movement amount.

[Default]

COMMAND DESCRIPTION

[Reference] **GS P, GS W**
 [Example]

GS P x y

[Name] **Set horizontal and vertical motion units**

[Format]

ASCII	GS	P	x	y
Hex	1D	50	x	y
Decimal	29	80	x	y

[Range] $0 \leq nL, nH \leq 255$

[Description] Sets the horizontal and vertical motion units to 1/x inch and 1/y inch respectively.
 When x is set to 0, the default setting value is used.
 When y is set to 0, the default setting value is used.

[Notes]

- The horizontal direction is perpendicular to the paper feed direction.
- In standard mode, the following commands use x or y, regardless of character rotation (upside-down or 90° clockwise rotation):
 - ① **Commands using x** : ESC SP, ESC \$, ESC \, GS L, GS W.
 - ② **Commands using y** : ESC 3, ESC J.
- This command does not affect the previously specified values.
- The calculated result from combining this command with others is truncated to the minimum value of the mechanical pitch or an exact multiple of that value.

[Default] $x = 204, y = 408$

[Reference] **ESC SP, ESC \$, ESC \, ESC 3, ESC J, GS L, GS W**

[Example]

① GS V m, ② GS V m n

[Name] **Select cut mode**

[Format]

① ASCII	GS	V	m	
Hex	1D	56	m	
Decimal	29	86	m	
② ASCII	GS	V	m	n
Hex	1D	56	m	n
Decimal	1D	86	m	n
Decimal	29	86	m	n

[Range]

① $m = 0, 1, 48, 49$
 ② $m = 65, 66, 0 \leq n \leq 255$

[Description] Selects cut mode and executes the cut command. *m* selects cut mode as follows:

m	Function
0, 48	Total cut.
1, 49	Partial cut.
65	Form feed (cut position + [n x vertical motion unit]) and total cut
69	Form feed (cut position + [n x vertical motion unit]) and partial cut

[Notes]

- This command is only enabled if set at the beginning of the line.
- The horizontal and vertical motion units are specified by **GS P**.
- If you execute the command, disable the parameter "Total Cut", the cut will be partial. If you want to effect a total cut you have to enable the parameter on the Set Up.


[Default]

[Reference] **ESC i, ESC m**

[Example]

GS W nL nH

[Name]	Set printing area width				
[Format]	ASCII	GS	W	nL	nH
	Hex	1D	57	nL	nH
	Decimal	29	87	nL	nH
[Range]	$0 \leq nL, nH \leq 255$ $0 \leq nL + nH \times 256 \leq 832$				
[Description]	Sets the printing area width to the area specified by <i>nL</i> and <i>nH</i> . • The left margin is set to $[(nL + nH \times 256) \times (\text{horizontal motion unit})]$ inches.				



[Notes]	<ul style="list-style-type: none"> • This command is only enabled if set at the beginning of the line. • If the right margin is greater than the printable area, the printing area width is set at maximum value. • If the printing area width = 0, it is set at the maximum value. • The horizontal and vertical motion units are specified by GS P. Changing the horizontal or vertical motion unit does not affect the current left margin. • The GS P command can change the horizontal (and vertical) motion unit. • However, the value cannot be less than the minimum horizontal movement amount and it must be in even units of the minimum horizontal movement amount.
---------	---

[Default]

[Reference] **GS L, GS P**

[Example]

GS ^ r t m

[Name]	Execute macro					
[Format]	ASCII	GS	^	r	t	m
	Hex	1D	5E	r	t	m
	Decimal	29	94	r	t	m
[Range]	$0 \leq r, t \leq 255$ $0 \leq m \leq 1$					
[Description]	Executes a macro. • <i>r</i> specifies the number of times to execute the macro. • <i>t</i> specifies the waiting time for executing the macro. The waiting time is $t \times 100$ msec. for each macro execution. • <i>m</i> specifies macro executing mode: When the LSB of $m = 0$, the macro is executed <i>r</i> times continuously at the interval specified by <i>t</i> . When the LSB of $m = 1$, after waiting for the period specified by <i>t</i> , the LED indicator blinks and the printer waits for the FEED button to be pressed. After the button is pressed, the printer executes the macro once. The printer repeats the operation <i>r</i> times.					
[Notes]	<ul style="list-style-type: none"> • This command has an interval of $(t \times 100 \text{ msec.})$ after a macro is executed by <i>t</i>. • If this command is received while a macro is being defined, the macro definition is aborted and the definition is cleared. • If the macro is not defined or if <i>r</i> is 0, nothing is executed. 					

COMMAND DESCRIPTION

- When the macro is executed by pressing the FEED button ($m=1$), the paper cannot be fed using the FEED button.

[Default]

[Reference]

GS :

[Example]

GS c

[Name]

Print counter

[Format]

ASCII	GS	c
Hex	1D	63
Decimal	29	99

[Description]

Sets the serial counter value in the print buffer and increments or decrements the counter value.

[Notes]

- After setting the current counter value in the print buffer as print data (a character string), the printer counts up or down based on the count mode set. The counter value in the print buffer is printed when the printer receives a print command or the buffer is full.
- The counter print mode is set using **GS C 0**.
- The counter mode is set using **GS C 1** or **GS C ;**.
- In count-up mode, if the counter value set by this command goes out of the counter operation range set by **GS C 1** or **GS C ;** it is forced to revert to the minimum value.
- In count-down mode, if the counter value set by this command goes out of the counter operation range set by **GS C 1** or **GS C ;** it is forced to revert to the maximum value.

[Default]

[Reference]

GS C 0, GS C 1, GS C 2, GS C ;

[Example]

GS f n

[Name]

Select font for HRI characters

[Format]

ASCII	GS	f	n
Hex	1D	66	n
Decimal	29	102	n

[Range]

$n = 0, 1, 48, 49$

[Description]

Selects a font for the HRI characters used when printing a bar code. n selects a font from the following table:

n	Font
0, 48	Font A
1, 49	Font B

[Notes]

HRI characters are printed at the position specified by **GS H**.

[Default]

$n = 0$

[Reference]

GS H, GS k

[Example]

GS h n

[Name]

Set bar code height

[Format]

ASCII	GS	h	n
Hex	1D	68	n
Decimal	29	104	n

COMMAND DESCRIPTION

[Range] $1 \leq n \leq 255$
 [Description] Sets the height of the bar code.
 n specifies the number of vertical dots.
 [Notes]
 [Default] $n = 162$ (20.25 mm)
 [Reference] **GS k**
 [Example]

① GS k m [d1...dk] NUL ② GS k m n [d1...dn]

[Name] **Print bar code**
 [Format] ① ASCII GS k m NUL
 Hex 1D 6B m 00
 Decimal 29 107 m 0
 ② ASCII GS k m n
 Hex 1D 6B m n
 Decimal 29 107 m n
 [Range] ① $0 \leq m \leq 20$
 ② $65 \leq m \leq 90$
 [Description] Selects a bar code system and prints the bar code. m selects a bar code system as follows:

	m	Bar code system	No. of characters	Remarks
①	0	UPC-A	$11 \leq k \leq 12$	$48 \leq d \leq 57$
	1	UPC-E	$11 \leq k \leq 12$	$48 \leq d \leq 57$
	2	EAN13 (JAN)	$12 \leq k \leq 13$	$48 \leq d \leq 57$
	3	EAN8 (JAN)	$7 \leq k \leq 8$	$48 \leq d \leq 57$
	4	CODE39	$1 \leq k$	$48 \leq d \leq 57, 65 \leq d \leq 90,$ 32, 36, 37, 43, 45, 46, 47
	5	ITF	$1 \leq k$ (even number)	$48 \leq d \leq 57$
	6	CODABAR	$1 \leq k$	$48 \leq d \leq 57, 65 \leq d1 \leq 68,$ 36, 43, 45, 46, 47, 58
	7	CODE93	$1 \leq k \leq 255$	$1 \leq d \leq 127$
	8	CODE128	$2 \leq k \leq 255$	$1 \leq d \leq 127$
	20	CODE32	$8 \leq k \leq 9$	$48 \leq d \leq 57$

COMMAND DESCRIPTION

②	65	UPC-A	$11 \leq n \leq 12$	$48 \leq d \leq 57$
	66	UPC-E	$11 \leq n \leq 12$	$48 \leq d \leq 57$
	67	EAN13 (JAN)	$12 \leq n \leq 13$	$48 \leq d \leq 57$
	68	EAN8 (JAN)	$7 \leq n \leq 8$	$48 \leq d \leq 57$
	69	CODE39	$1 \leq n \leq 255$	$48 \leq d \leq 57, 65 \leq d \leq 90, 32, 36, 37, 43, 45, 46, 47$
	70	ITF	$1 \leq n \leq 255$	$48 \leq d \leq 57$
	71	CODABAR	$1 \leq n \leq 255$	$48 \leq d \leq 57, 65 \leq d1 \leq 68, 36, 43, 45, 46, 47, 58$
	72	CODE93	$1 \leq n \leq 255$	$0 \leq d \leq 127$
	73	CODE128	$2 \leq n \leq 255$	$0 \leq d \leq 127$
	90	CODE32	$8 \leq n \leq 9$	$48 \leq d \leq 57$

[Notes]

- If d is outside of the specified range, the printer prints the following message: "BAR CODE GENERATOR IS NOT OK!" and processes the data which follows as normal data.
- If the horizontal size exceeds the printing area, the printer only feeds the paper.
- This command feeds as much paper as is required to print the bar code, regardless of the line spacing specified by **ESC 2** or **ESC 3**.
- After printing the bar code, this command sets the print position to the beginning of the line.
- This command is not affected by print modes (emphasized, double-strike, underline or character size), except for upside-down and justification mode.

[Notes per ①]

- This command ends with a NUL code.
- When the bar code system used is UPC-A or UPC-E, the printer prints the bar code data after receiving 11 (without check digit) or 12 (with check digit) bytes bar code data.
- When the bar code system used is EAN13, the printer prints the bar code data after receiving 12 (without check digit) or 13 (with check digit) bytes bar code data.
- When the bar code system used is EAN8, the printer prints the bar code data after receiving 7 (without check digit) or 8 (with check digit) bytes bar code data.
- The number of data for ITF bar code must be even numbers. When an odd number of data is input, the printer ignores the last received data.

[Notes per ②]

- If n is outside of the specified range, the printer stops command processing and processes the following data as normal data.

When CODE93
is used:

- The printer prints an HRI character (o) as a start character at the beginning of the HRI character string.
- The printer prints an HRI character (o) as a stop character at the end of the HRI character string.
- The printer prints an HRI character (n) as a control character (00H to 1FH and 7FH).

When CODE128
is used:

- When using CODE128 in this printer, please note the following regarding data transmission:
 - The top part of the bar code data string must be a code set selection character (CODE A, CODE B or CODE C) which selects the first code set.
 - Special characters are defined by combining two characters "{" and one character. ASCII character "{" is defined by transmitting "{" twice, consecutively.

COMMAND DESCRIPTION

Specific character	Data transmission		
	ASCII	Hex	Decimal
SHIFT	{S	7B, 53	123, 83
CODE A	{A	7B, 41	123, 65
CODE B	{B	7B, 42	123, 66
CODE C	{C	7B, 43	123, 67
FNC1	{1	7B, 31	123, 49
FNC2	{2	7B, 32	123, 50
FNC3	{3	7B, 33	123, 51
FNC4	{4	7B, 34	123, 52
'{'	{{	7B, 7B	123, 123

[Default]

[Reference]

GS H, GS f, GS h, GS w

[Example]

GS r n

[Name]

Transmit status

[Format]

ASCII GS r n
Hex 1D 72 n
Decimal 29 114 n

[Range]

$1 \leq n \leq 2, 49 \leq n \leq 50$

[Description]

Transmits the status specified by *n* as follows:

n Function

1, 49 Transmits paper sensor status (as for **ESC v**).

2, 50 Transmits drawer connector status (as for **ESC u 0**).

Paper sensor status (n = 1, 49)

Bit	Off/On	Hex	Decimal	Function
0,1	Off	00	0	Not used
	On	03	3	Not used
2,3	Off	00	0	Paper end sensor: paper present
	On	0C	12	Paper end sensor: paper not present
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

Drawer connector status (n = 2, 50)

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	Connector pin 3 at low level
	On	01	1	Connector pin 3 at high level
1	-	-	-	Undefined
2	-	-	-	Undefined
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

COMMAND DESCRIPTION

there may be a time lag between receiving the command and transmitting the status, depending on data buffer status.

[Default]

[Reference]

DLE EOT, ESC u, ESC v

[Example]

GS v 0 m xL xH yL yH d1...dk

[Name]

Print raster bit image.

[Format]

ASCII	GS	v	0	m	xL xH yL yH d1...dk
Hex	1D	76	30	m	xL xH yL yH d1...dk
Decimal	29	118	48	m	xL xH yL yH d1...dk

[Range]

$0 \leq m \leq 3, 48 \leq m \leq 51$
 $0 \leq xL \leq 255$
 $0 \leq xH \leq 255 (1 \leq xL + xH \times 256 \leq 65535)$
 $0 \leq yL \leq 255$
 $0 \leq yH \leq 8 (1 \leq yL + yH \times 256 \leq 2047)$
 $0 \leq d \leq 255$
 $k = (xL + xH \times 256) + (yL + yH \times 256)$
 (except for $k = 0$)

[Description]

Selects raster bit image mode. The value of m selects the mode as follows :

m	Mode
0, 48	Normal
1, 49	Double-width
2, 50	Double-height
3, 51	Quadruple

- xL, xH selects the number of data bits ($xL + xH \times 256$) in the horizontal direction for the bit image.
- yL, yH selects the number of data bits ($yL + yH \times 256$) in the vertical direction for the bit image.

[Notes]

- In standard mode for receipt paper, this command is effective only when there is no data in the print buffer.
- This command has no effect in all print modes (character size, emphasized, double-strike, upside-down, underline, hite/black reverse printing, etc.) for raster bit image.
- If the printing area width set by **GS L** and **GS W** is less than the minimum width, the printing area is extended to the minimum width only on the line in question. The minimum width means 1 dot in normal ($m=0, 48$) and double-height ($m=2, 50$), 2 dots in double-width ($m=1, 49$) and quadruple ($m=3, 51$) modes.
- Data outside the printing area is read in and discarded on a dot-by-dot basis.
- The position at which subsequent characters are to be printed for raster bit image is specified by **HT** (Horizontal Tab), **ESC \$** (Set absolute print position), **ESC** (Set relative print position), and **GS L** (Set left margin). If the position at which subsequent characters are to be printed is not a multiple of 8, print speed may decline.
- The **ESC a** (Select justification) setting is also effective on raster bit images.
- When this command is received during macro definition, the printer ends macro definition, and begins executing this command. The definition of this command should be cleared.
- d indicates the bit image data. Set time a bit to 1 prints a dot and setting it to 0 does not print a dot.

d1	d2	...	dx
dX+1	dX+2	...	dX x 2
:	:	...	:
...	dk-2	dk-1	dk

[Reference]

[Example]

GS w n

[Name] **Set bar code width**

[Format] ASCII GS w n
 Hex 1D 77 n
 Decimal 29 119 n

[Range] $1 \leq n \leq 6$

[Description] Sets the horizontal size of the bar code. *n* specifies the bar code width as follows:

n	Module width (mm)
1	0.125
2	0.25
3	0.375
4	0.5
5	0.625
6	0.75

[Notes]

[Default] n = 3

[Reference] **GS k**

[Example]

GS | n

[Name] **Set printing density**

[Format] ASCII GS | n
 Hex 1D 7C n
 Decimal 29 124 n

[Range] $0 \leq n \leq 12, 48 \leq n \leq 57, 65 \leq n \leq 67$

[Description] Sets printing density. *n* specifies printing density as follows:

n	Printing density
0, 48	- 50%
1, 49	- 37.5%
2, 50	- 25%
3, 51	- 12%
4, 52	Normal
5, 53	+ 12.5%
6, 54	+ 25%
7, 55	+ 37.5 %
8, 56	+ 50%
9, 57	+ 62.5 %
10, 65	+ 75%
11, 66	+ 87.5 %
12, 67	+ 100%

COMMAND DESCRIPTION

[Notes] • Printing density reverts to the default value when the printer is reset or turned off.
 [Default] n = 4
 [Reference]
 [Example]

GS { } n

[Name] **Set superscript/subscript**

[Format] ASCII GS { } n
 Hex 1D 7E n
 Decimal 29 126 n

[Range] n = 0, 1, 48, 49

[Description] Sets superscript or subscript character position. *n* specifies the position as follows:

n	Function
0, 48	Subscript character position
1, 49	Superscript character position

[Notes] • This command is executed if there are characters of different height on the same line.
 [Default] n = 0
 [Reference] **ESC !, GS !**
 [Example]

GS { } n

[Name] **Set printing speed**

[Format] ASCII GS { } n
 Hex 1D F0 n
 Decimal 29 240 n

[Range] $0 \leq n \leq 2$

[Description] Sets printing speed. *n* specifies the printing speed as follows:

n	Printing speed
0	Low
1	Normal
2	High

[Notes] • Printing speed reverts to the default value when the printer is reset or turned off.
 [Default] n = 1
 [Reference]
 [Example]

GS { } n

[Name] **Set current consumption in printing**

[Format] ASCII GS { } n
 Hex 1D F1 n
 Decimal 29 241 n

[Range] $0 \leq n \leq 2$

[Description] Sets current consumption in printing.

n specifies the absorption as follows:

n	Absorption in printing
0	Low (256 maximum dots ON at the same time - 2A rms)
1	Normal (512 maximum dots ON at the same time - 3A rms)
2	High (832 maximum dots ON at the same time - 5A rms)

- [Notes] • The medium current in printing is indicated with 50% dots ON.
 • The current absorption in printing reverts to the default value when the printer is reset or turned off.
- [Default] n = 1
- [Reference]
- [Example]

GS { }

- [Name] **Ticket align at the first printing line**
- [Format] ASCII GS { }
- Hex 1D F6
- Decimal 29 246
- [Description] This command searches a paper notch and then align the ticket at the first printing line.
- [Notes]
- [Default]
- [Reference] **GS 0xF8**
- [Example]

GS { }

- [Name] **Ticket align at cut**
- [Format] ASCII GS { }
- Hex 1D F8
- Decimal 29 248
- [Description] This command searches a paper notch and then align the ticket at cut.
- [Notes]
- [Default]
- [Reference] **GS 0xF6**
- [Example]