
Opoz RP5080 Printer Installation Guide

V1.0

Specification:


Printing Method	Direct thermal line printing
Dot Density	8 dots/mm
Printing Density	576 dots/line
MCBF	100 km
Printing Speed	150 mm/sec.
Printing Paper Width:	79±1 mm
Paper Diameter	Max < 80mm
MCBF of Auto Cutter	500,000 times
Power Supply	DC24V+10%
Power Consumption	2.5A
The Max current	Max 8A
Cash drawer interface	RJ11 – can support two cash drawers
Signal interface	36PIN Bi-directional parallel port or 25PIN D-SUB serial port
Dimension	139.2 (W) X 213 (D) X 123 (H) mm
Net Weight	1.135Kgs
Operating temperature	5~40 ℃
Relative humidity	10~80%RH
Input & output voltage	Input: 100-240V, 50/60Hz, MAX1.50A Output: 24V,2.5A,60W

Carton Content:




- 1. Printer
- 2. Test paper roll
- 3. Power adapter
- 4. Power cord
- 5. Signal cable

Installation



Connecting the Signal Cable

Before connecting any of the cables, make sure that both the printer and the host are turned off.




3. 36PIN connector

4. Signal connector of the printer

Insert the 36PIN connector into the signal connector of the printer


Fasten the 36PIN connector there




Insert the 25PIN D-SUB connector into the parallel port of the host unit and fasten the left and right screws.

Connecting the Power Adapter:

- Check the label on the power supply to make sure that the voltage required by the power supply matches that of your electrical outlet.
- Due to the power adapter is a high voltage product, the erector must have the relative professional skill. Otherwise may cause the power adapter damaged.







The installation is finished and you

Loading paper roll:

- Please choose high quality thermal paper, in order to protect the printer head.
- Do not use paper rolls that have the paper glued to the core because the printer • cannot detect the paper end correctly.
- Be sure to use right paper rolls that meet the specifications.



- 1. upper cover
- 2. lid button
- paper roll 3.
- paper-in slot 4.



Press the lid button and the upper cover will open.

Put the paper roll into the paper-in slot and pull out a small amount of paper.

Be sure to note the correct direction that the paper comes off the roll.

Close the upper cover.

The Self-test:

To start Self-test, press and hold down "FEED" button while power on, then release the button, the Self-test sample will be printed.

CITAQ CO., LTD.

Add: 6/F., Hanjiang Bldg., Changping Rd., Shantou, China Tel: 86 754 8845120 / 8845121 Fax: 86 754 8845109 www.citaq.com E-MAIL: info@citaq.com support@citaq.com